



CANopen User Manual

SOLO UNO and SOLO BETA models

SOLO Motor Controllers



Firmware versions supported: 0x0000B009 or later

Revision History:

Revision	Date	Changes
V1.0.0	06/09/2021	First Release



Contents:

Purpose of this user manual	7
CAN Bus Access points on SOLO UNO:	8
CAN Bus utilization on Legacy SOLO BETA models:	9
CAN Bus Setup:	10
CANopen Objects:	11
Types of CANopen Objects:	11
CANopen Message Structure:	12
The Arbitration Field (COB-ID + RTR):	13
COB-ID:	13
RTR Bit:	14
Node-ID	14
The Data Field:	14
Little Endian Format	14
CANopen NMT state machine:	15
BOOT-UP State:	17
Pre-Operational State:	17
Operational State	17
Stopped State	17
NMT Error Control:	18
Node Guarding	18
Life Guarding	18
Heartbeat:	20
BOOT-UP Message:	21
EMERGENCY Message:	21
SDO vs. PDO Message:	23
SDO Messages:	23
SDO Read Request:	24
Host Initiating the SDO Read Command:	24
Node replying to the SDO Read Request:	24



SOLO UNO Communication Manual - UART and USB

SDO Write Request:	25
Host attempts the SDO Write Command:	25
Node replying to the SDO Write Request:	25
SDO Abort Transfer Messages	26
Object Dictionary:	27
NMT Control Objects:	27
1001h : Read Error Register	27
100Ch : Guard Time	28
100Dh : Life Time Factor	28
1017h : Producer Heartbeat Time	28
SOLO UNO CANopen Objects:	29
3001h : Set Device Address	29
3002h : Commanding Mode	30
3003h : Current Limit	31
3004h : Torque Reference (Iq/IM)	31
3005h : Speed Reference	32
3006h : Power Reference	33
3007h : Motor's Parameters Identification	33
3008h : Emergency Stop	34
3009h : Output PWM Frequency (switching frequency)	34
300Ah : Speed Controller Kp Gain	35
300Bh : Speed Controller Ki Gain	35
300Ch : Motor's Direction of Rotation	36
300Dh : Motor's Phase or Armature Resistance	37
300Eh : Motor's Phase or Armature Inductance	37
300Fh : Motor's Number of Poles	38
3010h : Incremental Encoder's Lines	38
3011h : Speed Limit	38
3013h : Feedback Control Mode	39
3014h : Reset Factory	39
3015h : Motor Type	40
3016h : Control Mode Type	41
3017h : Current Controller Kp Gain (Torque controller)	41
3018h : Current Controller Ki Gain (Torque controller)	42
301Ah : Magnetizing Current Reference (Id)	42
301Bh : Position Reference	43



SOLO UNO Communication Manual - UART and USB

301Ch : Position Controller Kp Gain	43
301Dh : Position Controller Ki Gain	43
301Fh : Reset Position to Zero (Home)	44
3020h : Device Error Register	45
3021h : Sensorless Observer Gain for Normal BLDC-PMSM Motors	46
3022h : Sensorless Observer Gain for Ultra-fast BLDC-PMSM Motors	46
3023h : Sensorless Observer Gain for DC Brushed Motors	47
3024h : Sensorless Observer Filter Gain for Normal BLDC-PMSM Motors	47
3025h : Sensorless Observer Filter Gain for Ultra Fast BLDC-PMSM Motors	48
3026h : UART Baud-Rate	48
3027h : Encoder or Hall Sensors Calibration Start/Stop	49
3028h : Per-Unit Encoder or Hall sensor Counter Clockwise offset	49
3029h : Per-Unit Encoder or Hall sensor Clockwise offset	50
302Ah : Speed Acceleration Value	50
302Bh : Speed Deceleration Value	51
302Ch : CAN Bus Baud-rate	52
302Dh : Phase-A voltage	52
302Eh : Phase-B voltage	53
302Fh : Phase-A Current	53
3030h : Phase-B Current	53
3031h : BUS Voltage (Input Supply / Battery)	54
3032h : DC Motor Current (IM)	54
3033h : DC Motor Voltage (VM)	54
3034h : Quadrature Current (Iq)	55
3035h : Direct Current / Magnetizing Current (Id)	55
3036h : Speed Feedback	55
3037h : Position Feedback (Incremental Encoder)	56
3038h : Motor's Angle	56
3039h : Board Temperature	56
303Ah : Firmware Version	57
303Bh : Hardware Version	57
Data TYPES:	58
UINT32:	58
INT32:	58
Sfxt(32-17):	58
DATA Types Conversions:	59



SOLO UNO Communication Manual - UART and USB

Converting Sfmt(32-17) data type to floating point data type:	59
Converting float data type to Sfmt(32-17) data type :	60
Converting 32 bits Hex data to signed INT32 format:	61
Converting signed INT32 to 32bits Hex format:	62
CANopen Data communication examples	63
Set the Guard Time:	63
Set the Heartbeat production:	64
Control the Speed of a PMSM using Encoders:	64
Control the Speed of a BLDC using HALL sensors:	66
Control the Speed of a Brushless motor in Sensor-less mode:	67



Introduction

Purpose of this user manual

This user manual intends to address the technical and practical aspects of CANopen communication for communicating with SOLO UNO motor controller devices.

The CANopen interface for SOLO Motor Controllers follows the CiA DS301 communication profile, CiA (CAN in Automation) is the non-profit organization that governs the CANopen standard. They can be contacted at <http://www.can-cia.org>

CANopen is an open standard embedded machine control protocol. CAN is a serial communication interface and The CANopen protocol is developed for the CAN physical layer. In this document, CAN is reserved for physical layer descriptions, while CANopen refers to the communication protocol.

In this Manual the numbers in Hexa-decimal formats are shown either with an “h” at the end of the number like “0h” or with “0x” in the beginning of the number like “0x02”.

If after reading this manual or during your experimentations with our products you had any questions, you can use the SOLO Motor Controllers [Forum](#) to share with us the questions and get back your answers promptly.



CAN Bus Access points on SOLO UNO:

The CAN Bus on SOLO UNO can be accessed from two different sections as shown in Figure 1 below, The first section is the “CAN BUS/UART PINOUT” and the other one is located in “COMMUNICATION PORT” which both have the same functionality.




Figure 1- CAN bus access points on SOLO UNO

CAN Bus utilization on Legacy SOLO BETA models:

The CAN bus on legacy SOLO BETA models is not having the CAN transceiver IC mounted, so to use the CANopen functionality the user has to use an external CAN Transceiver module compatible with 3.3V CAN_TX and CAN_RX coming out of SOLO BETA as the CAN bus signals similar to Figure 2 below:




Figure 2 - CAN bus utilization on Legacy SOLO BETA models

CAN Bus Setup:

On the CAN bus, each units' CAN line is attached to the differential bus lines at CANH and CANL. Typically, the bus is a twisted pair of wires with a characteristic impedance of 120Ω , in the standard half-duplex multipoint topology. Each end of the bus should be terminated with 120Ω resistors in compliance with the standard to minimize signal reflections on the bus, the SOLO UNO units, don't have the 120Ω termination on the board and the user must apply it externally at each end of the bus line as shown in Figure 3 below:




Figure 3 - CAN bus setup

Each Node shown above can be any module with CANopen enabled topology and based on CANopen standards, up to 127 nodes can be connected together on a CAN bus.

CANopen Objects:

All the functionalities that are supported by CANopen in SOLO motor controllers devices are brought into different objects, so in essence, each object can relate to a specific task or drive functionality. (Speed reference, current limit, position reference, etc)

The drive has a unique object for every parameter that needs to be stored or used. Access to the objects vary depending on what the object is used for. Objects may be writable, readable, or both, all the objects that are supported by SOLO UNO are listed below.

Each object is accessible with a 16-bit address called the object index. Some objects contain sub components with 8-bit addresses called sub-indices. Reading and writing to objects is accomplished via CANopen Messages. Specific types of messages are designed to access specific objects.

Types of CANopen Objects:

SOLO UNO at this point supports two types of CANopen objects:

NMT Control Objects 1000h – 1FFFh: These objects relate to CANopen Network Management and functionalities like Node Guarding, Life Guarding, Heartbeat etc.

Manufacturer Specific Objects 3000h – 5FFFh: These objects are manufacturer Specific which are used to command the controller for setups or controlling, the details of all these objects can be found later in this manual.



CANopen Message Structure:

The message format for a CANopen frame is based on the CAN frame format. In the CAN protocol, the Data is transferred in frames consisting of an 11-bit or 29-bit CAN-ID, control bits such as the remote transfer bit (RTR), start bit and 4-bit Data length field, and 0 to 8 bytes of Data. The COB-ID, commonly referred to in CANopen, consists of the CAN-ID and the control bits. In CANopen, the 11-bit CAN ID is split into two parts: a 4-bit function code and a 7-bit CANopen node ID. The 7-bit size limitation restricts the amount of devices on a CANopen network to 127 nodes. All COB-IDs must be unique at any level to prevent conflicts on the bus.




Figure 4- CANopen Frame bit sequence

Within CANopen protocol, which is actually a software layer over CAN physical layer, the only two sections that are important for us are shown in BLUE which are the Arbitration Field and the Data field(COB-ID, RTR and the Data Field), the rest of the sections are automatically arranged by CAN protocol or should be taken care independently from the CANopen structure of messaging.

The Arbitration Field (COB-ID + RTR):

The values in the arbitration field set the priority of the message. The closer the value is to zero, the higher the priority of the message. Higher priority messages will dominate, or take other messages on the CAN bus. Arbitration of the CAN bus is done at the CAN hardware level, thus ensuring that the highest priority message is transmitted first. CANopen message priority is determined by the message COB-ID bits and the RTR (Remote Transmit Request) bit.

COB-ID:

Every CANopen message has a unique COB-ID that identifies the message type and in case of node specific messages, the node number. In the case of a range of COB-IDs, the actual COB-ID for a message will depend on which node receives or transmits the message. These COB-IDs begin with a base number (assigned in CiA's DS301 specification) and the addition of the NODE-ID completes the COB-ID. In another word, The COB-ID is either a fixed number or it's the result of the summation of the command code and the real Node ID which is also known as the address of the device in the network. You can see on Table 1 below some COB-ID ranges for SOLO Motor Controllers:

Table 1: CANopen message types

Message Type	Description	COB-ID
NMT	Network Management (broadcast)	0h
NMT ERROR CONTROL	Network management error control	701h - 77Fh
BOOT-UP	Boot-Up Message	701h - 77Fh
SYNC	Synchronization message (broadcast)	80h
EMERGENCY	Emergency messages	81h - FFh
PDO	Process Data Objects	181h - 57Fh
SDO	Service Data Objects	581h - 67Fh



RTR Bit:

The remote transmission request (RTR) bit is used in some specific cases when the host would like to request information from a node. In particular, the RTR bit is used for node guard and TPDO requests. With the exception of these two cases, the RTR bit is always set to zero.

Node-ID

Every node on the CANopen network must have a unique node-ID, between 1 and 127. Node 0 is always considered as the host. You can use the USB connection to change your SOLO's Node ID (device address) using the [Motion Terminal](#) as the easiest way.

The Data Field:

The content of the Data field depends on the CANopen message type, for each object the Data type and the range are given below in this manual.

Little Endian Format

Numerical Data larger than 1 byte must be organized into "Little Endian" format. This means that the Data is broken into its individual bytes and sent Least-Significant Byte first (LSB first). For instance a generic 32 bits Data of 0x87963510 is sent like 0x10 0x35 0x96 0x87 as shown below:

Arbitration Field		Data Field							
COB-ID	RTR	Byte1	Byte2	Byte3	Byte4	Byte5	Byte6	Byte7	Byte8
XXXh	X	0x10	0x35	0x96	0x87	0x00	0x00	0x00	0x00



CANopen NMT state machine:

The CANopen Network Management on SOLO follows the following state machine shown in Figure 5 below, the values shown on the arrows are called the events and they indicate what transition between the states will happen if an NMT Message with respective event comes through the CANopen network for the Node with the same Node ID based on the message structure shown in Table 2 below.




Figure 5 - Communication State Machine

Every CANopen device contains an internal Network Management server that communicates with an external NMT master. One device in a network, generally the host, may act as the NMT master. Through NMT messages, each CANopen device's network management server controls state changes within its built-in Communication State Machine. The Communication State Machine in all CANopen devices, is identical as specified by the DS301.

NMT messages have the highest priority. The 5 NMT messages that control the Communication State Machine each contain 2 Data bytes that identify the node number and a command to that node's state machine, table 2 below shows the general NMT state machine construction for sending these messages to SOLO Motor controllers devices:

Table 2 - NMT Message structure

Arbitration Field		Data Field							
COB-ID	RTR	Byte1	Byte2	Byte3	Byte4	Byte5	Byte6	Byte7	Byte8
000h	0	See Table 3	See Table 3	These Bytes are not sent					

Table 3 - NMT messages supported by SOLO Motor Controllers CANopen enabled devices

NMT Message	COB-ID	Data Byte 1	Data Byte 2	Description
Go to Operational State	0	01h	Node_ID	Sets the CANopen communication state machine on the designated node to Operational.
Go to Stopped State	0	02h	Node_ID	Sets the CANopen communication state machine on the designated node to Stopped.
Go to Pre-Operational State	0	80h	Node_ID	Sets the CANopen communication state machine on the designated node to Pre-Operational. In the pre-operational state, only NMT and SDO messages are allowed.
Reset the Node	0	81h	Node_ID	Resets the designated node (same as power recycle). Results in a Boot Up message sent by the node.
Reset the Communication	0	82h	Node_ID	Resets CANopen communication state machine on the designated node. Results in a Boot Up message sent by the node.



BOOT-UP State:

Upon Power up, the device will start the initialization process by checking critical functionalities and loading all the parameters saved on the memory. After Boot-up a message will be sent out and the drive will go to pre-operational state automatically.

Pre-Operational State:

Communication is limited to all message types except PDO messages. In this state, the Master can put the Device into any state possible shown in Table 3 based on the communication state diagram in Figure 5.

Operational State

Enables all message types including PDO messages. In this state, the NMT master can command the communication state to go into any state possible shown in Table 3 based on the communication state diagram in Figure 5.

Stopped State

Disables all message types except NMT messages; Node Guarding / Lifeguarding (explained below) remains active



NMT Error Control:

SOLO Motor Controller CANopen enable devices, support Node Guarding, Life Guarding, and Heartbeat protocol as NMT error controls.

Node Guarding

The NMT Master can monitor the communication status of each node using the Node Guarding protocol. During node guarding, a drive is polled periodically and is expected to respond with its communication state within a predefined time frame. Acceptable states are shown in Table 6. Note that responses indicating an acceptable state will alternate between two different values due to a toggle bit in the returned value. If there is no response, or an unacceptable state occurs, the NMT master reports an error to its host application. The Node Guard message is sent at time intervals, determined by the Guard Time (object 100Ch). The NMT slave (node) must reply to this message before the end of this time interval. Table 4 and Table 5 show the message format for an NMT master request and the correct NMT slave response. Note that the slave always responds with a toggle bit in byte 1, therefore the response will toggle between the two values shown in Table 6.

Life Guarding

The NMT slave monitors the status of the NMT master (Life Guarding). This event utilizes the Guard Time (object 100Ch) and Life Time Factor (object 100Dh) to determine a “Lifetime” for each NMT slave as shown in Figure 5 below ($\text{Lifetime} = \text{Guard Time} * \text{Life Time Factor}$). If a node does not receive a Node Guard message within its Lifetime, the node assumes communication with the host is lost and triggers a communication error event. Each node may have a different Lifetime.



Table 4: NMT Master Node Guard Request Message Format (Host to Node)

Arbitration Field		Data Field							
COB-ID	RTR	Byte1	Byte2	Byte3	Byte4	Byte5	Byte6	Byte7	Byte8
700h + Node-ID	1	These Bytes are not sent.							

Table 5: NMT Slave Node Guard Reply Message Format (Node to Host)

Arbitration Field		Data Field							
COB-ID	RTR	Byte1	Byte2	Byte3	Byte4	Byte5	Byte6	Byte7	Byte8
700h + Node-ID	0	See Table 6	These Bytes are not sent.						

Table 6: Acceptable NMT slave return values for the states

Communication Status	Possible return values
Pre-Operational	0x7F or 0xFF
Operational	0x05 or 0x85
Stopped	0x04 or 0x84






Figure 6- Life Time and Guard Time relation

As can be seen in Figure 6, the Life time can be an integer factor of the Guard time.

Heartbeat:

The heartbeat error control method uses a producer to generate a periodic message. One or more consumer devices on the network listen for this message. If the producer fails to generate a message within a specified time frame, the consumer acts accordingly. Any drive on the network can be configured to be a producer of heartbeat based on the most recent firmware on SOLO UNO controller, The producer heartbeat time (object 1017h) represents the time in milliseconds between successive heartbeat messages. It can be any integer value between 1 and 65535. When set to zero, the producer heartbeat is disabled.

BOOT-UP Message:

SOLO transmits a boot-up message after power up, communication reset, or power recycling. The CANopen master can monitor this and report an error if no boot-up message was received. The boot-up message of SOLO uses the same COB-ID as a Node Guard reply.

Arbitration Field		Data Field							
COB-ID	RTR	Byte1	Byte2	Byte3	Byte4	Byte5	Byte6	Byte7	Byte8
700h + Node-ID	0	0x00	These Bytes are not sent.						

EMERGENCY Message:

EMERGENCY messages are sent by the CANopen nodes to provide crucial status information to the CANopen host controller. An emergency message is transmitted only once per error event by the controller, it uses the message ID of “0x80” plus the Node ID as the COB-ID, as can be seen below, the index of Error register object is 1001h, and the errors can be overwritten using the object 3020h explained in object dictionary:

Arbitration Field		Data Field							
COB-ID	RTR	Byte1	Byte2	Byte3	Byte4	Byte5	Byte6	Byte7	Byte8
80h + Node-ID	0	0x00	0x00	0x00	Error Register (see table 7)	0x00	0x00	0x00	0x00



Table 7: Emergency Message Error Register bit description

Bit#	Error Status
0	Generic error
1	Current error
2	Voltage error
3	Temperature error
4	Communication error (overrun, error state)
5	Device profile specific error
6	Reserved (always 0)
7	Manufacturer-specific error



SDO vs. PDO Message:

There are two methods for reading and writing Data to an object, Service Data Object (SDO) and Process Data Object (PDO) messages. An SDO consists of an outgoing message from host to node, possibly some intermediate messages between host and node, and a reply message from node to host; this is referred to as confirmed messaging. A PDO consists of a single unconfirmed message that requires less bus traffic relative to its SDO counterpart. Although PDOs make more efficient use of the CAN bus than do SDOs, PDO messages must be configured prior to use, and at this moment SOLO UNO only supports SDO type of messaging on CANopen network, in near future, the PDO capability will be added to the firmware, However using the SDO messaging all the functionalities of SOLO UNO can be addressed and controlled.

SDO Messages:

Service Data objects (SDOs) enable access to all entries of a CANopen object dictionary. One SDO consists of two CAN Data frames with different CAN-Identifiers. This is a confirmed communication service. With an SDO, a peer-to-peer client-server communication between two CANopen devices can be established on the broadcast medium CAN. The owner of the accessed object dictionary acts as a server of the SDO. The device that accesses the object dictionary of the other device is the SDO client.



SDO Read Request:

The SDO read request is sent from Host to the respective Node to read a parameter that is “Readable” and the Node will reply back to the message as can be seen in the following format, it worth mentioning that each object in the object dictionary can have a sub-index which will define all the related sub-objects to the main object, and each can have a different functionality. If an object has a special sub-index it will be mentioned in the object dictionary.

Host Initiating the SDO Read Command:

Arbitration Field	Data Field							
COB-ID	Byte1	Byte2	Byte3	Byte4	Byte5	Byte6	Byte7	Byte8
600h + Node-ID	0x40	Object index (LSB)	Object index (MSB)	Sub-index	Use 0x00 for each byte			

Node replying to the SDO Read Request:

Arbitration Field	Data Field							
COB-ID	Byte1	Byte2	Byte3	Byte4	Byte5	Byte6	Byte7	Byte8
580h + Node-ID	0x42	Object index (LSB)	Object index (MSB)	Sub-index	Data, LSB first			



SDO Write Request:

The SDO Write Request is sent from Host to the respective Node to write a parameter or set a desired reference point for an object which is “Writable”, similar to Read request, the Write request is also composed out of a request followed by a message from the Node as below:

Host attempts the SDO Write Command:

Arbitration Field	Data Field							
COB-ID	Byte1	Byte2	Byte3	Byte4	Byte5	Byte6	Byte7	Byte8
600h + Node-ID	0x22	Object index (LSB)	Object index (MSB)	Sub-index	Data, LSB first			

Node replying to the SDO Write Request:

Arbitration Field	Data Field							
COB-ID	Byte1	Byte2	Byte3	Byte4	Byte5	Byte6	Byte7	Byte8
580h + Node-ID	0x60	Object index (LSB)	Object index (MSB)	Sub-index	ignore			



SDO Abort Transfer Messages

When an error occurs during reading or writing an object, the node sends an abort transfer message to the host.

Arbitration Field	Data Field							
COB-ID	Byte1	Byte2	Byte3	Byte4	Byte5	Byte6	Byte7	Byte8
580h + Node-ID	0x80	Object index (LSB)	Object index (MSB)	Sub-index	See Table 8 below for abort codes			

Table 8 : Node indicating error in SDO communication

Abort Codes	Description
0x06020000	Object does not exist in the object dictionary
0x06090030	Value range of parameter exceeded (only for write access)



Object Dictionary:

NMT Control Objects:

1001h : Read Error Register

Code: 0x1001	Read Error Register																						
Data Type	Data Range	Units	Accessibility	Memory Storage	Default Value																		
Uint32	[0-254]	N/A	R	V	0																		
<p>Description: This object reads the CANopen Error register, if the value of Data in the response is interpreted bit-wise, meaning that if each bit in the answer is 1 corresponding to error as shown in table below, to reset or overwrite the errors you can use the object 3020h.</p> <table border="1"> <thead> <tr> <th>Bit#</th> <th>Error Status</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Generic error</td> </tr> <tr> <td>1</td> <td>Current error</td> </tr> <tr> <td>2</td> <td>Voltage error</td> </tr> <tr> <td>3</td> <td>Temperature error</td> </tr> <tr> <td>4</td> <td>Communication error (overrun, error state)</td> </tr> <tr> <td>5</td> <td>Device profile specific error</td> </tr> <tr> <td>6</td> <td>Reserved (always 0)</td> </tr> <tr> <td>7</td> <td>Manufacturer-specific error</td> </tr> </tbody> </table>						Bit#	Error Status	0	Generic error	1	Current error	2	Voltage error	3	Temperature error	4	Communication error (overrun, error state)	5	Device profile specific error	6	Reserved (always 0)	7	Manufacturer-specific error
Bit#	Error Status																						
0	Generic error																						
1	Current error																						
2	Voltage error																						
3	Temperature error																						
4	Communication error (overrun, error state)																						
5	Device profile specific error																						
6	Reserved (always 0)																						
7	Manufacturer-specific error																						



100Ch : Guard Time

Code: 0x100C	Guard Time				
Data Type	Data Range	Units	Accessibility	Memory Storage	Default Value
Uint32	[0-65535]	ms	R/W	V	0
Description: This object reads or writes the value of the Guard Time in Milliseconds					

100Dh : Life Time Factor

Code: 0x100D	Life Time Factor				
Data Type	Data Range	Units	Accessibility	Memory Storage	Default Value
Uint32	[0-255]	N/A	R/W	V	0
Description: This object reads or writes the value of the Life Time Factor. Lifetime = Guard Time * Life Time Factor					

1017h : Producer Heartbeat Time

Code: 0x100D	Producer Heartbeat Time				
Data Type	Data Range	Units	Accessibility	Memory Storage	Default Value
Uint32	[0-65535]	ms	R/W	V	0
Description: This object reads or writes the value of the Heartbeat time in Milliseconds for a node to produce heartbeats at requested time.					



SOLO UNO CANopen Objects:

3001h : Set Device Address

Code: 0x3001	Set Device Address				
Data Type	Data Range	Units	Accessibility	Memory Storage	Default Value
Uint32	[1-254]	N/A	R/W	M	1
<p>Description: This object Sets or Reads the desired device address for a SOLO unit; the address can be used to network multiple SOLO's in a single network if the address assigned to each unit is unique. In the CANOpen network the address of "0" is not acceptable for a SOLO UNO unit, and if the address is set at "0", it will be considered as "1" automatically.</p>					



3002h : Commanding Mode

Code: 0x3002		Commanding Mode			
Data Type	Data Range	Units	Accessibility	Memory Storage	Default Value
Uint32	0 or 1	N/A	R/W	V	0

Description:

This object Sets or Reads the mode of the operation of SOLO in terms of operating in Analogue mode or Digital Mode based on the value of Data in the packet with as below:

Data	Actions
0 (0x00000000)	Puts SOLO in Analogue Mode
1 (0x00000001)	Puts SOLO in Digital Mode

Once in Analogue Mode some configuration can be done only at hardware level, as the table below suggests, everything else outside of the below table can be set only through sending Data packets to SOLO through UART, USB or CAN bus.

Action	In Analogue Mode	In Digital Mode
Open-Loop or Closed-Loop Operation	Through PIN 5 of Piano Switch	Through PIN 5 of Piano Switch
Motor Type selection	Through PIN 1 and 2 of Piano Switch	Set with object 0x3015
Control Mode selection (Torque, Speed, Position)	Through PIN 4 of Piano Switch (only Torque and Speed)	Set with object 0x3016 (Torque, Speed, Position)
DFU mode	Through PIN 3 of Piano Switch	Through PIN3 of Piano Switch
Current (Torque) controller Kp and Ki Gains in closed-loop mode	Auto-tuned after Motor Identification (Pressing Pin 5 of Piano Switch down while SOLO is ON while the PIN 5 is UP initially)	Set with object of 0x3017 and 0x3018 (Auto-tuned after Motor Identification)
Speed controller Kp and Ki Gains in closed-loop Speed mode	Through two physical potentiometers of Kp and Ki on the board	Set with object of 0x300A and 0x300B respectively
Speed Reference	Sent by PWM or Analogue voltages through S/T input on Analogue Input port	Set with object of 0x3005
Torque Reference	Sent by PWM or Analogue voltages through S/T input on Analogue Input port	Set with object of 0x3004
Power/ Current Limit / Magnetizing Current	Sent by PWM or Analogue voltages through P/F input on Analogue Input port	Set with objects of 0x3006, 0x3003 and 0x301A respectively



3003h : Current Limit

Code: 0x3003		Current Limit			
Data Type	Data Range	Units	Accessibility	Memory Storage	Default Value
Sfxt(32-17)	[0.2 - 32.0]	Amps	R/W	M	32
<p>Description: This object Sets or Reads the maximum allowed current into the motor in terms of Amps, this command will be effective only once SOLO is in closed-loop digital mode as in analogue mode the current limit is set through "P/F" input pin, In Regeneration Mode, SOLO will limit the current fed back into supply to this value.</p>					

3004h : Torque Reference (Iq/IM)

Code: 0x3004		Torque Reference (Iq/IM)			
Data Type	Data Range	Units	Accessibility	Memory Storage	Default Value
Sfxt(32-17)	[0 - 32.0]	Amps	R/W	V	0
<p>Description: This object Sets or Reads the amount of desired current that acts in torque generation. In 3-phase motors this is called Iq or quadrature current as SOLO operates in FOC mode, however for DC brushed motors this value sets the reference for IM in DC brushed motors. This command will be effective only once SOLO is in closed-loop digital Torque mode as in analogue mode the Torque reference is set through the "S/T" input pin once SOLO is in Torque Mode. For all the motors including DC, BLDC, PMSM and ACIM the value of the torque reference can relate to Torque on the shaft of the motor based on following relation: Requested Torque [N.m] = Torque Reference [A] x Motor's Torque constant [N.m/A]</p>					



3005h : Speed Reference

Code: 0x3005	Speed Reference				
Data Type	Data Range	Units	Accessibility	Memory Storage	Default Value
Uint32	[0 - 30,000]	RPM*	R/W	V	0

Description:

This object Sets or Reads the speed reference for SOLO once it's in Digital Speed Mode, as in analogue mode the reference is set through the "S/T" input pin with analogue voltages or PWM pulses once SOLO is in Speed Mode.

*The Speed Unit depends on the type of the Motor as well as the type of operation, and if SOLO is in Open-loop or Closed-loop it can take different meanings as shown below:

Motor Type (Analogue or Digital Mode)	Closed-loop Sensor-less	Closed-loop Sensor-based	Open-loop
BLDC - PMSM	RPM	RPM	RPM
BLDC - PMSM Ultrafast	RPM	RPM	RPM
DC Brushed	Motor Dependent**	RPM	Duty Cycle***
AC Induction Motor	RPM	RPM	RPM

Basically the major consideration will be for DC brushed motors while they are in Sensor-less or Open-loop Mode with the following conditions:

***Speed Unit for DC brushed motor in Closed-loop Sensor-less mode:** This is a qualitative value based on the observer gain defined for the sensorless speed estimator for DC brushed motors, the value can be ranged from 0 to 30,000 and the final speed of the motor for each value depends on the characteristics of the Motor itself like BEMF constant, the increase in the Motor's Speed with respect to the reference will be linear up until the nominal speed of the motor.

*****Speed Unit for DC brushed motor in Open-loop mode:** in This case the speed reference will act as the duty cycle percentage at the output on the Motor, the value can be between 0 to 30,000 which will be mapped into 0% duty cycle to 100% duty cycle, going from no speed to max speed.



3006h : Power Reference

Code: 0x3006		Power Reference			
Data Type	Data Range	Units	Accessibility	Memory Storage	Default Value
Sfxt(32-17)	[0 - 100.0]	N/A	R/W	V	0
<p>Description: This object Sets or Reads the amount of power percentage during only Open-loop mode for 3-phase motors. The value is from 0.0 to 100.0 standing for 0% to 100% output power on the shaft of the Motor.</p>					

3007h : Motor's Parameters Identification

Code: 0x3007		Motor Parameters Identification			
Data Type	Data Range	Units	Accessibility	Memory Storage	Default Value
Uint32	0 or 1	N/A	W	V	0
<p>Description: This object starts the Motor ID by putting value of 1 in the Data section of a packet sent with this command, SOLO will start identifying the electrical parameters of the Motor connected, The identification will take 1 second to be done and after that the Motor Inductance, Resistance and some internal parameters are Identified (or re-identified). Identification process depends on the type of the motor selected, so before running the Identification the user has to make sure they have properly selected their motor type both in Analogue or Digital Mode.</p>					



3008h : Emergency Stop

Code: 0x3008		Emergency Stop			
Data Type	Data Range	Units	Accessibility	Memory Storage	Default Value
Uin 32	0	N/A	R/W	V	1
<p>Description: In this object if the Data is set at zero it will stop the whole power and switching system connected to the motor and it will cut the current floating into the Motor from SOLO, by sending this command SOLO should be power recycled to get back into normal operation externally.</p>					

3009h : Output PWM Frequency (switching frequency)

Code: 0x3009		Output PWM Frequency (switching frequency)			
Data Type	Data Range	Units	Accessibility	Memory Storage	Default Value
Uin32	[8 - 8000]	Hz/kHz	R/W	M	20000 / 80000
<p>Description: This object Sets the output switching frequency of the whole power unit on the Motor, SOLO UNO supports switching frequencies from 8 to 80kHz and the user can set their desired frequency with steps of 1kHz from 8 to 80kHz once writing into this object, however once you Read the switching frequency using this object, the returned value will be in Hertz format. As a rule of thumb, Higher switching frequencies are necessary for Motors with Low inductance (below 200uH), but the increase or decrease of this value should be done carefully, as increasing the switching frequency is not always good and it can cause saturation and excessive loss for both the magnetic cores of the Motor and the SOLO unit itself if the Motor under control can not support such high frequencies. The whole internal algorithms including samplings in SOLO are synchronized to the switching frequency.</p>					



300Ah : Speed Controller Kp Gain

Code: 0x300A		Speed Controller Kp gain			
Data Type	Data Range	Units	Accessibility	Memory Storage	Default Value
Sfxt(32-17)	[0 - 300.0]	N/A	R/W	M	0
<p>Description: This object Sets or Reads the Speed controller Kp Gain, and it will be functional only in Digital Closed-loop mode, since in Analogue mode this gain is set using the Potentiometer named with “Kp” locally on the board. This is the proportional gain of the PI controller that SOLO uses to control to stabilize the speed of a motor on a given reference point in close-loop mode, This gain is normally for most motors takes a value in between 0.001 to 0.5 but there might be some cases that you need to go even higher, the user has to increase/decrease these gains with care as they can cause instability for the device under test if not selected properly.</p>					

300Bh : Speed Controller Ki Gain

Code: 0x300B		Speed Controller Ki gain			
Data Type	Data Range	Units	Accessibility	Memory Storage	Default Value
Sfxt(32-17)	[0 - 300.0]	N/A	R/W	M	0
<p>Description: This object Sets or Reads the Speed controller Ki gain, and it will be functional only in Digital Closed-loop mode, since in Analogue mode this gain is set using the Potentiometer named with “Ki” locally on the board. This is the integral gain of the PI controller that SOLO uses to control to stabilize the speed of a motor on a given reference point, This gain is normally for most motors takes a value in between 0.0001 to 0.01 but there might be some cases that you need to go even higher, the user has to increase/decrease these gains with care as they can cause instability for the device under test if not selected properly. In theory, this gain helps the system to have zero steady-state error.</p>					



300Ch : Motor's Direction of Rotation

Code: 0x300C	Motor Direction of Rotation				
Data Type	Data Range	Units	Accessibility	Memory Storage	Default Value
Uint32	0/1	N/A	R/W	V	0

Description:

This object Sets or Reads the direction of the rotation of the motor either in ClockWise rotation or Counter Clockwise Rotation based on the table below,(In sensorless Modes, the order of the wirings of the motor can invert the direction of rotation with respect to table below)

Data	Desired Rotational Direction
0 (0x00000000)	Counter ClockWise
1 (0x00000001)	ClockWise



300Dh : Motor's Phase or Armature Resistance

Code: 0x300D	Motor's Phase or Armature Resistance				
Data Type	Data Range	Units	Accessibility	Memory Storage	Default Value
Sfxt(32-17)	[0.001 - 50.0]	Ohm	R/W	M	0
<p>Description: This object Sets or Reads the amount of the Phase or Armature resistance for 3-phase or DC Brushed motors respectively. This value is automatically identified by SOLO after Motor Identification but in any case it's possible for the user to alter the values as they like. After changing these values manually, for them to take effect a power recycle is required.</p>					

300Eh :Motor's Phase or Armature Inductance

Code: 0x300E	Motor's Phase or Armature Inductance				
Data Type	Data Range	Units	Accessibility	Memory Storage	Default Value
Sfxt(32-17)	[0.00005 - 0.2]	Henry	R/W	M	0
<p>Description: This object Sets or Reads the amount of the Phase or Armature Inductance for 3-phase or DC Brushed motors respectively. This value is automatically identified by SOLO after Motor Identification but in any case it's possible for the user to alter the values as they like. After changing these values manually, for them to take effect a power recycle is required.</p>					



300Fh : Motor's Number of Poles

Code: 0x300F		Motor's Number of Poles			
Data Type	Data Range	Units	Accessibility	Memory Storage	Default Value
Uint32	[1-254]	N/A	R/W	M	8
<p>Description: This object Sets or Reads the number of the Poles of a 3-phase motor commissioned with SOLO, in case of BLDC or PMSM motors, the Number of poles is equal to the number of magnets on the rotor of the Motor, for ACIM motors, the user has to refer to the technical Datasheet of their motor to find this parameter.</p>					

3010h : Incremental Encoder's Lines

Code: 0x3010		Incremental Encoder's Lines			
Data Type	Data Range	Units	Accessibility	Memory Storage	Default Value
Uint32	[1-200,000]	pre-quad	R/W	M	1000
<p>Description: This object Sets or Reads the pre-quad number of physical lines of an incremental encoder engraved on its disk, in another form it can be seen as the number of pulses generated on 1 line of the Encoder output once it is rotated for 1 exact round.</p>					

3011h : Speed Limit

Code: 0x3011		Speed Limit			
Data Type	Data Range	Units	Accessibility	Memory Storage	Default Value
Uint32	[0-30,000]	RPM	R/W	M	30,000
<p>Description: This object Sets or Reads the allowed speed during trajectory following in closed-loop position controlling mode, it can be used to change the speed of a position follower during motion, or it can be fixed on a desired value.</p>					



3013h : Feedback Control Mode

Code: 0x3013		Feedback Control Mode											
Data Type	Data Range	Units	Accessibility	Memory Storage	Default Value								
UInt32	[0-2]	N/A	R/W	M	0								
<p>Description: This object Sets or Reads the type of the feedback control SOLO has to operate with based on table below both in Analogue or Digital Mode:</p> <table border="1"> <thead> <tr> <th>Data</th> <th>Operation</th> </tr> </thead> <tbody> <tr> <td>0 (0x00000000)</td> <td>Operates in Sensor-less feedback Mode</td> </tr> <tr> <td>1 (0x00000001)</td> <td>Operates in Incremental Encoder feedback Mode (calibration required)</td> </tr> <tr> <td>2 (0x00000002)</td> <td>Operates in HALL Sensors feedback Mode (calibration required)</td> </tr> </tbody> </table>						Data	Operation	0 (0x00000000)	Operates in Sensor-less feedback Mode	1 (0x00000001)	Operates in Incremental Encoder feedback Mode (calibration required)	2 (0x00000002)	Operates in HALL Sensors feedback Mode (calibration required)
Data	Operation												
0 (0x00000000)	Operates in Sensor-less feedback Mode												
1 (0x00000001)	Operates in Incremental Encoder feedback Mode (calibration required)												
2 (0x00000002)	Operates in HALL Sensors feedback Mode (calibration required)												

3014h : Reset Factory

Code: 0x3014		Reset Factory			
Data Type	Data Range	Units	Accessibility	Memory Storage	Default Value
UInt32	1	N/A	R/W	V	0
<p>Description: This object resets SOLO to its factory setting to all the default parameters, after this command a power recycle is required so that the default values take effect, the Data sent within this object to reset the device should be "0x00000001".</p>					



3015h : Motor Type

Code: 0x3015		Motor Type			
Data Type	Data Range	Units	Accessibility	Memory Storage	Default Value
Uint32	[0-3]	N/A	R/W	M	0

Description:

This object Sets or Reads the Motor type that is connected to SOLO in Digital Mode based on the following table if the requested Data is placed in a packet sent with the object 0x3015, the user has to note that in Analogue Mode the Motor Type is only selected by Piano Switch mounted on SOLO using PIN 1 and 2 (refer to SOLO UNO user manual to know more)

Data	Motor Type
0 (0x00000000)	Selects DC brushed Motor in Digital Mode
1 (0x00000001)	Selects Normal BLDC-PMSM Motor in Digital Mode
2 (0x00000002)	Selects ACIM Motor in Digital Mode
3 (0x00000003)	Selects Ultra fast BLDC-PMSM Motor in Digital Mode



3016h : Control Mode Type

Code: 0x3016		Control Mode Type											
Data Type	Data Range	Units	Accessibility	Memory Storage	Default Value								
Uint32	[0-2]	N/A	R/W	M	1								
<p>Description: This object Sets or Reads the Control Mode in terms of Torque, Speed or Position only in Digital Mode based on the following table, in Analogue Mode this functionality is selected by using Piano switch PIN 4 for only Torque and Speed controlling functionalities. (refer to SOLO UNO user manual to know more)</p> <table border="1"> <thead> <tr> <th>Data</th> <th>Control Mode Type</th> </tr> </thead> <tbody> <tr> <td>0 (0x00000000)</td> <td>Operates in Speed Mode</td> </tr> <tr> <td>1 (0x00000001)</td> <td>Operates in Torque Mode</td> </tr> <tr> <td>2 (0x00000002)</td> <td>Operates in Position Mode</td> </tr> </tbody> </table>						Data	Control Mode Type	0 (0x00000000)	Operates in Speed Mode	1 (0x00000001)	Operates in Torque Mode	2 (0x00000002)	Operates in Position Mode
Data	Control Mode Type												
0 (0x00000000)	Operates in Speed Mode												
1 (0x00000001)	Operates in Torque Mode												
2 (0x00000002)	Operates in Position Mode												

3017h : Current Controller Kp Gain (Torque controller)

Code: 0x3017		Current Controller Kp (Torque controller)			
Data Type	Data Range	Units	Accessibility	Memory Storage	Default Value
Sfxt(32-17)	[0 - 16000.0]	N/A	R/W	M	0
<p>Description: This object Sets or Reads the value for Current Controller Kp or proportional gain, which will be used in the PI controller that controls the current (torque) inside of the motor both in Analogue or Digital Mode, this value is automatically identified by SOLO after Motor Identification but in any case it's possible for the user to alter this value as they like. After changing this value manually, for them to take effect a power recycle is required.</p>					



3018h : Current Controller Ki Gain (Torque controller)

Code: 0x3018		Current Controller Ki Gain (Torque controller)			
Data Type	Data Range	Units	Accessibility	Memory Storage	Default Value
Sfxt(32-17)	[0 - 16000.0]	N/A	R/W	M	0
<p>Description: This object Sets or Reads the value for Current Controller Ki or integral gain, which will be used in the PI controller that controls the current (torque) inside of the motor both in Analogue or Digital Mode, this value is automatically identified by SOLO after Motor Identification but in any case it's possible for the user to alter this value as they like. After changing this value manually, for them to take effect a power recycle is required.</p>					

301Ah : Magnetizing Current Reference (Id)

Code: 0x301A		Magnetizing Current Reference (Id)			
Data Type	Data Range	Units	Accessibility	Memory Storage	Default Value
Sfxt(32-17)	[0 - 32.0]	Amps	R/W	V	0
<p>Description: This object Sets or Reads the desired magnetizing current (Id) required for controlling ACIM motors in FOC in Amps, it can be used only in Closed-loop digital mode, since in Analogue mode the Magnetizing current reference is set through Pin "P/F" (refer to SOLO UNO user manual to know more)</p>					



301Bh : Position Reference

Code: 0x301B	Position Reference				
Data Type	Data Range	Units	Accessibility	Memory Storage	Default Value
Int32	[-2,147,483,647 to 2,147,483,647]	Quad-Pulse	R/W	V	0
Description: This object Sets or Reads the desired Position reference in terms of quadrature pulses to follow for the position controller; this functionality will be available only once SOLO is in Close-loop Digital Position mode.					

301Ch : Position Controller Kp Gain

Code: 0x301C	Position Controller Kp Gain				
Data Type	Data Range	Units	Accessibility	Memory Storage	Default Value
Sfxt(32-17)	[0 - 16000.0]	N/A	R/W	M	0
Description: This object Sets or Reads the value for Position Controller Kp or proportional gain, which will be used in the PI controller that controls the position.					

301Dh : Position Controller Ki Gain

Code: 0x301D	Position Controller Ki Gain				
Data Type	Data Range	Units	Accessibility	Memory Storage	Default Value
Sfxt(32-17)	[0 - 16000.0]	N/A	R/W	M	0
Description: This object Sets or Reads the value for Position Controller Ki or integrator gain, which will be used in the PI controller that controls the position.					



301Fh : Reset Position to Zero (Home)

Code: 0x301F	Reset Position to Zero (Home)				
Data Type	Data Range	Units	Accessibility	Memory Storage	Default Value
UInt32	1	N/A	W	V	0
<p>Description: This object Sets the position counter back to zero if in the Data part of the packet the value of "0x00000001" is placed.</p>					



3020h : Device Error Register

Code: 0x3020	Device Error Register				
Data Type	Data Range	Units	Accessibility	Memory Storage	Default Value
Uint32	N/A	N/A	R/W	V	0

Description:

This object Reads or Overwrites the reported errors in Device Error Register. The purpose of error overwriting is to allow the user to see the problems transparently and decide what to do, but SOLO will always keep track of catastrophic errors and it will not ignore them. The following table is the bit arrangement of the error register, if any of the mentioned errors occurs, you will receive “1” in the position of the bit corresponding to the error in a 32 bits register shown below, so if the value of the error register is anything other than Zero, it means there is a problem somewhere, which can be found exactly by checking the following bits. By putting zero in the place of each bit and sending a command with an object “0x3020” the error bits can be overwritten, similarly by sending a Data part with only zeros inside, the whole error register will be overwritten. Once the error is over-written if it’s cause of existence is removed, SOLO will return back to normal operation, otherwise it will stay in fault mode without any switching at the output.

Bit Number	Error Description
0	Over-current error, while the current in the motor rises above 62A for more than 0.1ms
1	Over-voltage on BUS error, when the BUS voltage rises above 57V for more than 35us
2	Over Temperature Error, when the board temperature rises above 85 degrees
3	Encoder Calibration timeout - Index pulse is missing
4	Hall Sensors Calibration timeout
5	CAN Communication Lost (lifeTime expired)
6	N/A



3021h : Sensorless Observer Gain for Normal BLDC-PMSM Motors

Code: 0x3021		Sensorless Observer Gain for Normal Brushless Motor			
Data Type	Data Range	Units	Accessibility	Memory Storage	Default Value
Sfxt(32-17)	[0.01 - 1000]	N/A	R/W	M	0.9
<p>Description: This object Sets or Reads the observer gain for the Non-linear observer that estimates the speed and angle of a BLDC or PMSM once the motor type is selected as normal BLDC-PMSM. This Observer Gain basically deals with the Motor Back EMF Estimation, and normally it has a value from 0.01 to 1.0 for regular operations. In General, the Motors with higher Electrical time constant need less values for this observer gain, Electrical Time constant can be driven from division of Inductance over Resistance of the Motor's phases. This observer gain will be used both in Analogue and Digital Mode for Sensor-less operations and the gain can be modified dynamically in run-time.</p>					

3022h : Sensorless Observer Gain for Ultra-fast BLDC-PMSM Motors

Code: 0x3022		Sensorless Observer Gain for Ultra-fast BLDC-PMSM Motors			
Data Type	Data Range	Units	Accessibility	Memory Storage	Default Value
Sfxt(32-17)	[0.01 - 1000]	N/A	R/W	M	0.99
<p>Description: This object Sets or Reads the observer gain for the Non-linear observer that estimates the speed and angle of a BLDC or PMSM once the motor type is selected as ultra-fast BLDC-PMSM. This Observer Gain basically deals with the Motor Back EMF Estimation, and normally it has a value from 0.01 to 1.0 for regular operations. In General, the Motors with higher Electrical time constant need less values for this observer gain, Electrical Time constant can be driven from division of Inductance over Resistance of the Motor's phases. This observer gain will be used both in Analogue and Digital Mode for Sensor-less operations and the gain can be modified dynamically in run-time.</p>					



3023h : Sensorless Observer Gain for DC Brushed Motors

Code: 0x3023		Sensorless Observer Gain for DC Brushed Motors			
Data Type	Data Range	Units	Accessibility	Memory Storage	Default Value
Sfxt(32-17)	[0.01 - 1000]	N/A	R/W	M	50
<p>Description: This object Sets or Reads the observer gain for the Non-linear observer that estimates the speed of a DC brushed once the motor type is selected as DC brushed. This Observer Gain basically deals with the Motor Back EMF Estimation, and normally it has a value from 10 to 100 for regular operations. This observer gain will be used both in Analogue and Digital Mode for Sensor-less operations and the gain can be modified dynamically in run-time.</p>					

3024h : Sensorless Observer Filter Gain for Normal BLDC-PMSM Motors

Code: 0x3024		Sensorless Observer Filter Gain for Normal BLDC-PMSM Motors			
Data Type	Data Range	Units	Accessibility	Memory Storage	Default Value
Sfxt(32-17)	[0.01 - 16000]	N/A	R/W	M	50
<p>Description: This object Sets or Reads how fast the observer should operate once SOLO is in sensorless mode with normal BLDC-PMSM selected as the Motor type. Generally this gain can have values from 1 to 1000 and the lower the gain, the better will be the performance in Higher speeds. For tuning purposes, the user needs to check the behaviour of the motor for different values other than default value and try to find at what gain the performance is at best. The best method is to start around the default gain and try to reduce or increase the gain with steps of 2X, 3X, 4X, ... and so on to be able to see the significance of any change on the final result. The reason for this is if this gain is changed with very small steps, the user might not be able to see any difference, so once a good region is found, the user can start tuning the gain around that value with more accuracy.</p>					



3025h : Sensorless Observer Filter Gain for Ultra Fast BLDC-PMSM Motors

Code: 0x3025		Sensorless Observer Filter Gain for Ultra Fast BLDC-PMSM Motors			
Data Type	Data Range	Units	Accessibility	Memory Storage	Default Value
Sfxt(32-17)	[0.01 - 16000]	N/A	R/W	M	10

Description:

This object Sets or Reads how fast the observer should operate once SOLO is in sensorless mode with ultra-fast BLDC-PMSM selected as the Motor type. Generally this gain can have values from 1 to 1000 and the lower the gain, the better will be the performance in Higher speeds. For tuning purposes, the user needs to check the behaviour of the motor for different values other than default value and try to find at what gain the performance is at best. The best method is to start around the default gain and try to reduce or increase the gain with steps of 2X, 3X, 4X, ... and so on to be able to see the significance of any change on the final result. The reason for this is if this gain is changed with very small steps, the user might not be able to see any difference, so once a good region is found, the user can start tuning the gain around that value with more accuracy.

3026h : UART Baud-Rate

Code: 0x3026		Set UART Baud-Rate			
Data Type	Data Range	Units	Accessibility	Memory Storage	Default Value
Uint32	0/1	Bits/s	R/W	M	937500

Description:

This object Sets or Reads the baud-rate of the UART line, currently there are two baudrates supported by SOLO UNO, and they can be selected by sending either 0 or 1 in Data section of the packet , if the value of the Baud-rate is changed, to make it effective a power recycle is necessary.

Data	Baud-Rate [bits/s]
0 (0x00000000)	937500 (compatible with 921600)
1 (0x00000001)	115200



3027h : Encoder or Hall Sensors Calibration Start/Stop

Code: 0x3027		Encoder or Hall Sensors Calibration Start/Stop			
Data Type	Data Range	Units	Accessibility	Memory Storage	Default Value
Uint32	[0-2]	N/A	W	V	0

Description:
 This object starts or stops the process of sensor calibration based on the table below if the Data is sent as table below. The sensor calibration is done in full torque mode limited to Current Limit value. The Encoder or Hall sensor calibration is only necessary for 3-phase motors and in case of incremental encoders the presence of index pulse is mandatory to find the correct mechanical offset of the shaft of the motor with respect to the control unit.

Data	Action
0 (0x00000000)	Stop the calibration process
1 (0x00000001)	Start Incremental Encoder Calibration
2 (0x00000002)	Start Hall Sensors Calibration

3028h : Per-Unit Encoder or Hall sensor Counter Clockwise offset

Code: 0x3028		Per-Unit Encoder or Hall sensor Counter Clockwise offset			
Data Type	Data Range	Units	Accessibility	Memory Storage	Default Value
Sfxt(32-17)	[0.0-1.0]	N/A	R/W	M	0

Description:
 This object starts or stops the per-unit offset identified after sensor calibration for Encoder or Hall sensors in C.C.W direction, the value must be between 0 to 1 and it gets automatically updated each time after sensor calibration, however the users can insert their desired value dynamically.



3029h : Per-Unit Encoder or Hall sensor Clockwise offset

Code: 0x3029	Per-Unit Encoder or Hall sensor Clockwise offset				
Data Type	Data Range	Units	Accessibility	Memory Storage	Default Value
Sfxt(32-17)	[0.0-1.0]	N/A	R/W	M	0
<p>Description: This object Sets or Reads the per-unit offset identified after sensor calibration for Encoder or Hall sensors in C.W direction, the value must be between 0 to 1 and it gets automatically updated each time after sensor calibration, however the users can insert their desired value dynamically.</p>					

302Ah : Speed Acceleration Value

Code: 0x302A	Speed Acceleration Value				
Data Type	Data Range	Units	Accessibility	Memory Storage	Default Value
Sfxt(32-17)	[0.0-1600.0]	Rev/S ²	R/W	M	0
<p>Description: This object Sets or Reads the acceleration value of the Speed for speed controller both in Analogue and Digital modes in Revolution per square seconds, this value only has effect once SOLO is in Speed control mode and it will be ignored once in Torque or Position Mode.</p>					



302Bh : Speed Deceleration Value

Code: 0x302B		Speed Deceleration Value			
Data Type	Data Range	Units	Accessibility	Memory Storage	Default Value
Sfxt(32-17)	[0.0-1600.0]	Rev/S ²	R/W	M	0
<p>Description: This object Sets or Reads the deceleration value of the Speed for speed controller both in Analogue and Digital modes in Revolution per square seconds, this value only has effect once SOLO is in Speed control mode and it will be ignored once in Torque or Position Mode. Defining deceleration can reduce the regenerative power going back to supply as the speed reduces slowly. The deceleration will be by passed (fast stop) if the user sends the following speed references based on following table:</p>					
Mode		Speed Reference for fast stop with regeneration			
Digital Control		0			
Analogue Control PWM input		Duty cycle of 0.5% or less			
Analogue Control Voltage input		Voltage of 5mV or less			



302Ch : CAN Bus Baud-rate

Code: 0x302C	CAN Bus Baud-rate																
Data Type	Data Range	Units	Accessibility	Memory Storage	Default Value												
Uint32	[0-4]	kbits/s	R/W	M	1000												
<p>Description: This object Sets or Reads the Baud-rate of CAN bus in CANopen network based on the following table, after changing the Baud-rate a power cycle is required for SOLO so the new Baud-rate can take effect.</p> <table border="1"> <thead> <tr> <th>Data</th> <th>CAN bus Baud-rate [kbits/s]</th> </tr> </thead> <tbody> <tr> <td>0 (0x00000000)</td> <td>1000</td> </tr> <tr> <td>1 (0x00000001)</td> <td>500</td> </tr> <tr> <td>2 (0x00000002)</td> <td>250</td> </tr> <tr> <td>3 (0x00000003)</td> <td>125</td> </tr> <tr> <td>4 (0x00000004)</td> <td>100</td> </tr> </tbody> </table>						Data	CAN bus Baud-rate [kbits/s]	0 (0x00000000)	1000	1 (0x00000001)	500	2 (0x00000002)	250	3 (0x00000003)	125	4 (0x00000004)	100
Data	CAN bus Baud-rate [kbits/s]																
0 (0x00000000)	1000																
1 (0x00000001)	500																
2 (0x00000002)	250																
3 (0x00000003)	125																
4 (0x00000004)	100																

302Dh : Phase-A voltage

Code: 0x302D	Phase-A voltage				
Data Type	Data Range	Units	Accessibility	Memory Storage	Default Value
Sfxt(32-17)	[-60 - 60]	Volts	R	V	0
<p>Description: This object reads the phase-A voltage of the motor connected to the “A” pin output of SOLO for 3-phase Motors.</p>					



302Eh : Phase-B voltage

Code: 0x302E		Phase-B voltage			
Data Type	Data Range	Units	Accessibility	Memory Storage	Default Value
Sfxt(32-17)	[-60 - 60]	Volts	R	V	0
Description: This object reads the phase-B voltage of the motor connected to the “B” pin output of SOLO for 3-phase Motors.					

302Fh : Phase-A Current

Code: 0x302F		Phase-A Current			
Data Type	Data Range	Units	Accessibility	Memory Storage	Default Value
Sfxt(32-17)	[-32 - 32]	Amps	R	V	0
Description: This object reads the phase-A current of the motor connected to the “A” pin output of SOLO for 3-phase Motors.					

3030h : Phase-B Current

Code: 0x3030		Phase-B Current			
Data Type	Data Range	Units	Accessibility	Memory Storage	Default Value
Sfxt(32-17)	[-32 - 32]	Amps	R	V	0
Description: This object reads the phase-B current of the motor connected to the “B” pin output of SOLO for 3-phase Motors.					



3031h : BUS Voltage (Input Supply / Battery)

Code: 0x3031		BUS Voltage (Input Supply / Battery)			
Data Type	Data Range	Units	Accessibility	Memory Storage	Default Value
Sfxt(32-17)	[0 - 60]	Volts	R	V	0
Description: This object reads the input BUS voltage.					

3032h : DC Motor Current (IM)

Code: 0x3032		DC Motor Current (IM)			
Data Type	Data Range	Units	Accessibility	Memory Storage	Default Value
Sfxt(32-17)	[-32 - 32]	Amps	R	V	0
Description: This object reads the current inside the DC brushed motor connected to “B” and “C” outputs of SOLO UNO.					

3033h : DC Motor Voltage (VM)

Code: 0x3033		DC Motor Voltage (VM)			
Data Type	Data Range	Units	Accessibility	Memory Storage	Default Value
Sfxt(32-17)	[-60 - 60]	Volts	R	V	0
Description: This object reads the voltage of the DC brushed motor connected to “B” and “C” outputs of SOLO UNO.					



3034h : Quadrature Current (Iq)

Code: 0x3034		Quadrature Current (Iq)			
Data Type	Data Range	Units	Accessibility	Memory Storage	Default Value
Sfxt(32-17)	[-64.0 - 64.0]	Amps	R	V	0
<p>Description: This object reads the actual monetary value of “Iq” that is the current acts in torque generation in FOC mode for 3-phase motors, the amount of Torque on the shaft of the motor can be calculated using the following formula: Actual Torque [N.m] = Iq [A] * Motor’s Torque constant [N.m/A]</p>					

3035h : Direct Current / Magnetizing Current (Id)

Code: 0x3035		Direct Current / Magnetizing Current (Id)			
Data Type	Data Range	Units	Accessibility	Memory Storage	Default Value
Sfxt(32-17)	[-64.0 - 64.0]	Amps	R	V	0
<p>Description: This object reads the actual monetary value of Id that is the direct current acting in FOC, this current for ACIM motors is known as Magnetizing current as well.</p>					

3036h : Speed Feedback

Code: 0x3036		Speed Feedback			
Data Type	Data Range	Units	Accessibility	Memory Storage	Default Value
Int32	[-30,000 - 30,000]	RPM	R	V	0
<p>Description: This object reads the actual speed of the motor measured or estimated by SOLO in sensorless or sensor-based modes respectively.</p>					



3037h : Position Feedback (Incremental Encoder)

Code: 0x3037		Position Feedback (Incremental Encoder)			
Data Type	Data Range	Units	Accessibility	Memory Storage	Default Value
Int32	[-2,147,483,647 to 2,147,483,647]	Quad-Pulses	R	V	0
Description: This object reads the number of counted pulses from the Incremental Encoder in Quadrature manner.					

3038h : Motor's Angle

Code: 0x3038		Motor's Angle			
Data Type	Data Range	Units	Accessibility	Memory Storage	Default Value
Sfxt(32-17)	[-2 - 2]	Per Unit	R	V	10
Description: This object reads the measured or estimated per-unit angle of the 3-phase motors.					

3039h : Board Temperature

Code: 0x3039		Board Temperature			
Data Type	Data Range	Units	Accessibility	Memory Storage	Default Value
Sfxt(32-17)	[-30.0 - 150.0]	°C	R	V	0
Description: This object reads the momentary temperature of the board in centigrade.					



303Ah : Firmware Version

Code: 0x303A	Firmware Version				
Data Type	Data Range	Units	Accessibility	Memory Storage	Default Value
Uint32	N/A	N/A	R	M	N/A
<p>Description: This object reads the Firmware version existing currently on the SOLO unit, the Data section of the received command will contain a Number like "0x0000B009" which will indicate the firmware version.</p>					

303Bh : Hardware Version

Code: 0x303B	Hardware Version				
Data Type	Data Range	Units	Accessibility	Memory Storage	Default Value
Uint32	N/A	N/A	R	M	N/A
<p>Description: This object reads the Hardware version of the SOLO unit connected.</p>					



Data TYPES:

The Data types in SOLO UNO are categorized into three main types as shown in table below:

Name	Value	Size[bits]	Range	Resolution
UINT32	Unsigned Integer	32	[0 to 4,294,967,295]	+/- 1
INT32	Signed Integer	32	[-2,147,483,647 to 2,147,483,647]	+/- 1
Sfxt(32-17)	Fixed Point	32	[-16,384.000 to 16,384.000]	+/- 0.00000762

UINT32:

This Data type is used for Unsigned Integer values and it occupies 32 bits.

INT32:

This Data type is used for Signed Integer values and it occupies 32 bits.

Sfxt(32-17):

This Data type is used to represent the variables with floating point and it occupies 32 bits.

To send and receive commands or feedback properly during communication with SOLO, you need to convert your Data into one of these forms based on the command or feedback that you are using, as each command has a specific Data type.

In all of these formats, the Data section occupies 32 bits or 4 bytes, below you can see how one can convert these Data types to tangible numbers from Hexadecimal format that is the default way of sending or receiving Data with SOLO, in this manual the Hexadecimal numbers are either shown with "0x" in the beginning of the number or "h" at the end of the number.



DATA Types Conversions:

Converting Sfmt(32-17) data type to floating point data type:

If the DATA section of a packet received from SOLO, contains a number in Fixed-Point format, you can use the following two methods to convert it back to a floating point data type depending on the sign of the received data and whether if it's a positive value or a negative value:

Condition1) If the data read from SOLO is less than or equal to 0x7FFE0000 (Hex) or 2,147,352,576 (decimal), This means the data is positive, so follow the following steps

- 1) Convert the hex data read from SOLO into Decimal format
- 2) The float number = data read from SOLO (in Decimal format) / 131072

Condition2) If the data read from SOLO is greater than 0x7FFE0000 (Hex) or 2147352576 (decimal), This means the data is negative, so the conversion will be as :

- 1) Subtract the data from 0xFFFFFFFF and then add a 0x1 to it (add 1 to it)
- 2) Convert the result of step "1" into Decimal format
- 3) The float number = (data in Decimal format taken from step "2" /131072) * -1

Example1 _ positive Numbers:

Data read from SOLO is "0x00030000"

So it's a Positive Numbers Conversion since the data read from SOLO is less than or equal to 0x7FFE0000 so the conversion will be:

- 1) Decimal (0x00030000) = 196608
- 2) $196608 / (131072) = 1.5$

Example2 _ negative Numbers:

Data read from SOLO is "0xFFCCDD2"

So it's a Negative Numbers Conversion since the data read from SOLO is greater than 0x7FFE0000, so the conversion will be:

- 1) $(0xFFFFFFFF - 0xFFCCDD2) + 0x1 = 0x0003322E$
- 2) Decimal (0x0003322E) = 209454
- 3) $(209454 / (131072)) * -1 = -1.598$



Converting float data type to Sfmt(32-17) data type :

If the DATA section of a packet to be sent to SOLO, contains a number in Fixed-Point format, you can use the following two methods to convert your real world float number into a Sfmt(32-17) data type depending on the sign of the float data and whether if it's a positive value or a negative value:

Condition1) If the float number is Positive:

- 1- Multiply the float number into 131072
- 2- Round down the result into the nearest integer value
- 3- convert this value to HEX

Condition2) If the float number is Negative:

- 1- Multiply the float number into 131072
- 2- Round down the result into the nearest integer value
- 3- Ignore the sign of the integer and convert this value to HEX (compute the Absolute value)
- 4- Subtract data from "0xFFFFFFFF"

Example 1_ positive float number:

Data to be sent : 4.2

Conversion:

- 1) $4.2 * 2^{17} = 550,502.4$
- 2) $\text{Round}(550502.4) = 550502$
- 3) $\text{Hex}(550502) = 0x0086666$

Example 2_ negative float number:

Data to be sent : -14.36

Conversion:

- 1) $-14.36 * 2^{17} = -1,882,193.92$
- 2) $\text{Round}(-1,882,193.92) = -1,882,193$
- 3) $\text{Hex}(\text{abs}(-1,882,193)) = 0x001CB851$
- 4) $0xFFFFFFFF - 0x001CB851 = 0xFFE347AE$



Converting 32 bits Hex data to signed INT32 format:

If you want to convert a DATA part of a packet read from SOLO into the real world Int32 format, based on the sign of the DATA you will fact the following two conditions for the conversion:

Condition1) If the data read from SOLO is less than or equal to 0x7FFFFFFF(Hex) or 2147483647 (decimal), This means the data is positive

When the data is positive, we can treat it like a normal unsigned value, so you can just directly convert the Hex value to decimal with known methods.

Condition2) If the data read from SOLO is greater than 0x7FFFFFFF(Hex) or 2147483647(decimal), This means the data is negative, so the conversion will be as :

- 1) Subtract the data from 0xFFFFFFFF and then add a 0x1 to it (add 1 to it)
- 2) Convert the result of step "1" into Decimal format
- 3) Multiply the result of step 3 to "-1"

Example 1_ positive Numbers:

Data read from SOLO is "0x0003F393"

- The data is smaller than 0x7FFFFFFF so it becomes : Dec (0x0003F393) = +258963

Example 2_ negative Numbers:

Data read from SOLO is "0xFFFFCA8AD"

- The data is bigger than 0x7FFFFFFF so we will have:

1. $(0xFFFFFFFF - 0xFFFFCA8AD) + 1 = 0x00035753$
2. $\text{Dec}(0x00035753) = 218963$
3. $218963 * -1 = -218963$



Converting signed INT32 to 32bits Hex format:

If you want to convert an INT32 value to a Hex formatted number to place in the DATA part of a packet to send to SOLO, based on the sign of the data you want to send, you will face the following two conditions for the conversion:

Condition1) If the data is positive:

If the number you want to send is positive, the only thing you need to do is converting the integer into HEX like an unsigned value

Condition1) If the data is Negative:

For sending negative Integers with Hex format to SOLO, you need to follow the following steps:

1. Subtract the absolute value of your number from 4294967295(Decimal) or 0xFFFFFFFF(Hex)
2. Add 1 to the result of step 1
3. Convert the result of 2nd step to Hex

Example 1_ positive Numbers:

Data to be sent: 1536

- Hex (1536) = 0x00000600

Example 2_ negative Numbers:

Data to be sent: -56329

- Hex (4294967295 - Abs (-56329) + 1) = 0xFFFF23F7



CANopen Data communication examples

The following is a set of examples showing how one can set or read some of the objects on SOLO in CANopen network, in all of these examples:

1. The Node or Device address is considered as “1”
2. All of the numbers in the table are having Hexadecimal format
3. The Remote messages will have an “r” extension in front of their COB-ID
4. Inside the “Message and Data” section the order of the bytes from left to right is Byte 0 to Byte8.

Set the Guard Time:

In this example we want to set the Guard time of the CANopen on SOLO UNO at 3000ms, so SOLO within this guard time should report the NMT state once asked by a remote packet from the server as below:

COB-ID	Number of Bytes	Message and Data	Description
601	8	22 0C 10 00 B8 0B 00 00	Set the Guard time at 3000 ms by server
581	8	60 0C 10 00 00 00 00 00	Node 1 responds back
701r	0	RTR set	Server Sends a remote Guard Request
701	1	FF	Node 1 responds indicating pre-operational mode within 3 seconds
701r	0	RTR set	Server Sends a remote Guard Request
701	1	7F	Node 1 responds indicating pre-operational mode within 3 seconds
701r	0	RTR set	Server Sends a remote Guard Request
701	1	FF	Node 1 responds indicating pre-operational mode within 3 seconds



Set the Heartbeat production:

This example wants to set the SOLO UNO unit to produce a heartbeat with intervals of 1000ms in between.

COB-ID	Number of Bytes	Message and Data	Description	Time stamp[ms]
601	8	22 17 10 00 E8 03 00 00	Server requests the 1s heartbeat	854.73
581	8	60 17 10 00 00 00 00 00	Node 1 responds back	854.73
701	1	7F	Node 1 indicates in pre-operational state	855.72
701	1	7F	Node 1 indicates in pre-operational state	856.71
701	1	7F	Node 1 indicates in pre-operational state	857.70

Control the Speed of a PMSM using Encoders:

In this example we want to do a close-loop speed control on a PMSM with 1000 lines of encoder lines, the goal is to set the speed at 1000 RPM, before sending the commands you just need to make sure SOLO is in Closed-loop mode (PIN NO# 5 of Piano Switch on SOLO UNO is Down), so in this case we just need to tune the Speed controller Kp and Ki gains.

Another point to consider is in this example we have identified the motor parameters beforehand and the wirings and the calibration values for the Encoder and the Motor are found using [this Tutorial](#).



SOLO UNO Communication Manual - UART and USB

COB-ID	Number of Bytes	Message and Data	Description
601	8	22 15 30 00 01 00 00 00	Set Motor type to Normal BLDC-PMSM
581	8	60 15 30 00 00 00 00 00	Node 1 responds
601	8	22 16 30 00 00 00 00 00	Set the Control mode type on Speed Mode
581	8	60 16 30 00 00 00 00 00	Node 1 responds
601	8	22 0A 30 00 33 33 00 00	Set the Speed Controller Kp Gain to 0.01
581	8	60 0A 30 00 00 00 00 00	Node 1 responds
601	8	22 0B 30 00 68 00 00 00	Set the Speed Controller Ki Gain to 0.0008
581	8	60 0B 30 00 00 00 00 00	Node 1 responds
601	8	22 0F 30 00 08 00 00 00	Set the Number of Poles at 8
581	8	60 0F 30 00 00 00 00 00	Node 1 responds
601	8	22 13 30 00 01 00 00 00	Set Control Mode on Sensor-based with Incremental Encoders
581	8	60 13 30 00 00 00 00 00	Node 1 responds
601	8	22 10 30 00 E8 03 00 00	Set the Encoder Lines at 1000 lines
581	8	60 10 30 00 00 00 00 00	Node 1 responds
601	8	22 02 30 00 01 00 00 00	Put SOLO in Digital Command Mode
581	8	60 02 30 00 00 00 00 00	Node 1 responds
601	8	22 05 30 00 E8 03 00 00	Set the Speed reference at 1000 RPM
581	8	60 05 30 00 00 00 00 00	Node 1 responds



Control the Speed of a BLDC using HALL sensors:

In this example we want to do a close-loop speed control on a BLDC to set the speed at 1000 RPM, before sending the commands you just need to make sure SOLO is in Closed-loop mode (PIN NO# 5 of Piano Switch on SOLO UNO is Down), so in this case we just need to tune the Speed controller Kp and Ki gains. Another point to consider is in this example we have identified the motor parameters beforehand and the wirings and the calibration values for the Encoder and the Motor are found using [this Tutorial](#).

COB-ID	Number of Bytes	Message and Data	Description
601	8	22 15 30 00 01 00 00 00	Set Motor type to Normal BLDC-PMSM
581	8	60 15 30 00 00 00 00 00	Node 1 responds
601	8	22 16 30 00 00 00 00 00	Set the Control mode type on Speed Mode
581	8	60 16 30 00 00 00 00 00	Node 1 responds
601	8	22 0A 30 00 00 00 01 00	Set the Speed Controller Kp Gain to 0.5
581	8	60 0A 30 00 00 00 00 00	Node 1 responds
601	8	22 0B 30 00 68 00 00 00	Set the Speed Controller Ki Gain to 0.0008
581	8	60 0B 30 00 00 00 00 00	Node 1 responds
601	8	22 0F 30 00 08 00 00 00	Set the Number of Poles at 8
581	8	60 0F 30 00 00 00 00 00	Node 1 responds
601	8	22 13 30 00 02 00 00 00	Set Control Mode on Sensor-based with Hall sensors
581	8	60 13 30 00 00 00 00 00	Node 1 responds
601	8	22 02 30 00 01 00 00 00	Put SOLO in Digital Command Mode
581	8	60 02 30 00 00 00 00 00	Node 1 responds
601	8	22 05 30 00 E8 03 00 00	Set the Speed reference at 1000 RPM
581	8	60 05 30 00 00 00 00 00	Node 1 responds



Control the Speed of a Brushless motor in Sensor-less mode:

In this example we want to do a sensorless close-loop speed control on a Brushless motor to set the speed at 6000 RPM, before sending the commands you just need to make sure SOLO is in Closed-loop mode (PIN NO# 5 of Piano Switch on SOLO UNO is Down), so in this case we just need to tune the Speed controller Kp and Ki gains. (We imagined the Motor Identification is done beforehand; to auto tune the current controller gains at least one time)

COB-ID	Number of Bytes	Message and Data	Description
601	8	22 15 30 00 01 00 00 00	Set Motor type to Normal BLDC-PMSM
581	8	60 15 30 00 00 00 00 00	Node 1 responds
601	8	22 16 30 00 00 00 00 00	Set the Control mode type on Speed Mode
581	8	60 16 30 00 00 00 00 00	Node 1 responds
601	8	22 0A 30 00 33 33 00 00	Set the Speed Controller Kp Gain to 0.01
581	8	60 0A 30 00 00 00 00 00	Node 1 responds
601	8	22 0B 30 00 68 00 00 00	Set the Speed Controller Ki Gain to 0.0008
581	8	60 0B 30 00 00 00 00 00	Node 1 responds
601	8	22 0F 30 00 08 00 00 00	Set the Number of Poles at 8
581	8	60 0F 30 00 00 00 00 00	Node 1 responds
601	8	22 13 30 00 00 00 00 00	Set Control Mode on Sensor-less
581	8	60 13 30 00 00 00 00 00	Node 1 responds
601	8	22 02 30 00 01 00 00 00	Put SOLO in Digital Command Mode
581	8	60 02 30 00 00 00 00 00	Node 1 responds
601	8	22 05 30 00 70 17 00 00	Set the Speed reference at 6000 RPM
581	8	60 05 30 00 00 00 00 00	Node 1 responds

