

PCB Wire to Board Header Pinouts

EmotiGlass Prototype Revision 1.2
 Jason Meyers, David Prutchi 20181017

PCBs here are shown looking at outside of glasses (wearer is looking at you).
 Left and Right are as worn.

Wire wrap wire (30AWG) with kynar or teflon insulation is recommended
 for connections. Battery connections and ground wiring should either be
 doubled or use 26 AWG wire.

All signals are wired from the Right Side PCB directly to their corresponding
 header or attachment point, with the exception of pins 1-6 of P30 which are wired
 to P21. Battery pigtail ground should be wired to P14.



