



Assembly note:

PCB1 bottom side must be connected with top side of PCB2 via JP1-4
 JP1 with JP1 and so on...

SOCKET CONVERTER		
ZIN18 => IN18		
www.NixieTester.com		Design: Marcin Saj
Date: 14 April 2021	Sheet: 1/1	V1