



! Please note that your headphones should have a volume control knob.
 ! If your headphones do have a volume control knob, you don't need RV1.
 ! If your headphones don't have a volume control, then insert potentiometer RV1 to regulate the volume. It would be extremely loud otherwise.

Sheet: /Microphone_Preamplifier/	
File: mic_preamp.sch	
Title: AGC Microphone Preamp	
Size: A4	Date:
KiCad E.D.A. kicad (5.1.6)-1	Rev: 1
	Id: 2/3