



Lower resistance ensures a lower reference voltage, which facilitates amplification (even with bad tolerances)

using 100ohm resistor for LED

using 100k potentiometer

using 1k resistor

Author: Carlos Garcia Saura
 License: Creative Commons Attribution-ShareAlike 4.0 International
<https://creativecommons.org/licenses/by-sa/4.0/>
<https://hackaday.io/project/27508-open-radiation-detector/>

Sheet: /
 File: open_rad_detector.sch

Title: Open Radiation Detector

Size: User	Date:	Rev: 0.9
KiCad E.D.A. kicad 4.0.6-e0-634952ubuntu16.10.1		Id: 1/1