# TENVIS

the world in my eyes

Quick Start Guide

For security's sake, please update the default user name and password of your IP camera. The exact process is on page 5 & 9.

Please download the latest **Quick Start Guide** from *www.tenvis.com/download*.

Contents

Chapter 1: Let's get started

## Chapter 2: Let's get PC view

Chapter 3: Let's get mobile view

Chapter 4: Last, but not least

Chapter 1: Let's get started

What's in the box

Wireless IP Camera x 1

Wi-Fi Antenna x 1

Power Adapter x 1

User Manual x 1

CD x 1

Mounting Bracket(set) x 1

Screws and Plastic Screw Anchors

Stickers

Let's show you around

Lan — WIFI
Audio Out — Power
Reset

Reset
Lan — Power
Power — Reset

WIFI
Lan

How it works

Wired LAN View

IP Camera — Wired — Wireless Router — Wired — PC/MAC

LAN WIFI

Mobile Phone

PAD

Wireless LAN View

Wired

Wireless

LAN WIFI

IP Camera

Wireless Router

PC/MAC

Mobile Phone

PAD

Internet View

Wired
or
Wireless

Internet

ADSL Modem

3G/4G or WIFI

IP Camera

Wirelesss Router

PC/MAC

Mobile Phone

PAD

LAN means Local Area Network

Chapter 2: Let's get PC view

For Windows

Wired LAN View

1. Insert the CD or download the software from *www.tenvis.com/download*.

2. Open the CD and use autorun to install. Then click ⭐ **IPCamWizard** .

3. After installation, please double click

4. Open the wizard and select the installation mode. **Wizard Mode** is recommended for first time users or non-tech users. If you select the Advanced Mode, please visit *www.tenvis.com/download* to find the **Advanced User Guide**.

5. Please make sure both the IP camera and your computer are connected with the wireless router.

6. Search and select your camera.


IP ADD:HTTP://192.168.1.239:81
User: admin   Pwd: <null>
S/N: xxxx
DDNS:http://xxxx.tenvis.info

You can find this label on the camera

7. Set the IP address of the camera. If a red arrow appears, it means you could visit your camera with your internal network through the browser. If not appear, please click **One Key Set**. If the red arrow still not appear, please contact us.

Step 3: Setting IP Address

Please save the Access URL in your memo

Tips: IP Camera Web Server will detect the type of your browser and match the correct sign-in mode accordingly.

Please install the plug-in of the IE browser for the first time

If you can view the scene, congratulations! Now you can view the live video from your LAN.

⚠ For the security, please update the default user name and password of your IP camera. The exact process is as below.

 ➡ **System** ➡ **Change Password**

If you only use wired LAN view, you could exit now.

Wireless LAN View

8. Please come back to the IP Camera Wizard page, fulfill the factory setting to continue.

IP ADD:HTTP://192.168.1.239:81
User: admin   Pwd: <null>
S/N: xxxx
DDNS:http://xxxx.tenvis.info

You can find this label on the camera

9. Please make sure the **Using Wireless Lan** is checked if you want to enable WIFI. And then click the **Scan** button until you find your own wireless router ID. When the scanning is finished, please select your WIFI network , and enter the password in **Share Key** text box. Then click **Apply**. The camera will be restarting, and the network cable need to be disconnected.


Please scan for multiple times!

Now move back to your browser. If you can view the scene, congratulations! You have set the wireless successfully.

If you don't use internet, now you could exit the IP Camera Wizard.

Internet View

10. If the DDNS checking succeed, please click **Next**. If failed, please recheck the Internet connecting. If still not connected, please contact your own Internet Service Provider.

11. If the port forwarding succeed, please click **Next**. If failed, please click **Set port forwarding**.

Please enter the router's username and password

Select your router brand, input the user name and password of your router, then click **OK**. If failed again, and the below 3 problems occur, please contact your Internet Service Provider or router provider.
1) You are not sure about the username or password.
2) You are not sure about your router brand;
3) You still can't set successful.

If you still have problem with port forwarding, please contact us by the support information on Page 19.

12. If succeed, below screen will show. If you want to add more cameras, please click **Next** and **Yes**.

Please save this important information in your memo

Now move back to your browser. Input your internet access URL. If you can view the scene, Congratulations! You have finished Internet view setting successfully. Now you can monitor what is happening anywhere anytime from internet.

For Mac

1. Insert the CD or download the software from
   www.tenvis.com/download.

2. Click .

"IP Camera Tool   " is an application downloaded from the Internet. Are you sure you want to open it?

Safari downloaded this file today at 上午9:23 from apps.tenvis.com.

[Show Web Page]   [Cancel]   [**Open**]

3. If you see the scene 1, please continue. If you see the scene 2, first skip to page 10 and modify the camera's IP address, and refresh to scene 1 to continue.

scene 1

IP Camera Tool

Anonymous   http://192.168.1.239:81

scene 2

IP Camera Tool

IP Camera   Subnet doesn't match, dbclick to change !

4. Double click the IP address listed in the search result window. Default browser will be opened automatically to display the camera login page.


IP ADD:HTTP://192.168.1.239:81
User: admin   Pwd: <null>
S/N: xxxx
DDNS:http://xxxx.tenvis.info

You can find this label on the camera

5. Access the camera via browser directly by typing in the camera's IP address.

Tips: IP Camera Web Server will detect the type of your browser and match the correct sign-in mode accordingly.

Congratulations! You have finished wired LAN view for MAC successfully.

⚠ For the security, please update the default user name and password of your IP camera. The exact process is as below.

 ➡ **System** ➡ **Change Password**

If you need wireless LAN view or Internet view for MAC, please visit *www.tenvis.com*.

Solution procedure to the scene 2 on page 8

Take the secondary click (right click) and select **Network Configuration** to set the IP address of the camera to the same subnet as LAN.

Make sure there's no IP address conflict.

PIC 1 and 2 can be found by the following steps:

Setting

Chapter 3: Let's get mobile view

For iPhone

1. Open the **app store** , and search tenvis, then install
CamViewer for IP Webcams. Or visit *www.tenvis.com/download* to know more.

2. Run **CamViewer for IP Webcams**. Then click **+**.

iPod	16:45	
Edit	**Camera Feeds**	**+**

3. For LAN view, please fulfill them below.

iPod	16:47	
Cancel	**Edit Camera**	Done
Name		TENVIS
Address		http://192.168.1.239:81
Username		admin
Password		*Please provide*
Connection		*Default (Audio Capable)*

For windows, this address is LAN access URL which you can find on page 7

LAN access URL: http://192.168.1.239:81

IP ADD:HTTP://192.168.1.239:81
User: admin   Pwd: <null>
S/N: xxxx
DDNS:http://xxxx.tenvis.info

You can find this label on the camera

For Internet view, please fulfill them below.

iPod	16:48	
Cancel	**Edit Camera**	Done
Name		TENVIS
Address		http://xxxx.tenvis.info
Username		admin
Password		*Please provide*
Connection		*Default (Audio Capable)*

For windows, this address is Internet access URL which you can find on page 7

Internet access URL: http://xxxx.tenvis.info

IP ADD:HTTP://192.168.1.239:81
User: admin   Pwd: <null>
S/N: xxxx
DDNS:http://xxxx.tenvis.info

You can find this label on the camera

Tips: The IP address and hostname in the snapshot is just for your reference.
For the MAC user, please visit *www.tenvis.com/support* for more info.

4. Select the camera you added and view the images from the camera.

Congratulations! You have finished iPhone view successfully, now you can view the live video from your iPhone anywhere anytime.

For Android

1. Search **IP Cam Viewer** in Google Play, you could install **IP Cam Viewer Lite** for simple use. Or visit *www.tenvis.com/download* to know more.
Click **+** and select **IP Camera, DVR, NVR**.

2. If your camera model doesn't show in the list, you could choose JPT3815.

For LAN view, please fulfill them below.

For windows, this address is LAN access URL which you can find on page 7

LAN access URL: http://192.168.1.239:81

IP ADD:HTTP://192.168.1.239:81
User: admin   Pwd: <null>
S/N: xxxx
DDNS:http://xxxx.tenvis.info

You can find this label on the camera

For Internet view, please fulfill them below.

For windows, this address is Internet access URL which you can find on page 7

Internet access URL: http://xxxx.tenvis.info

IP ADD:HTTP://192.168.1.239:81
User: admin   Pwd: <null>
S/N: xxxx
DDNS:http://xxxx.tenvis.info

You can find this label on the camera

Tips: The IP address and hostname in the snapshot is just for your reference.

3. Click test and save it. Then Click ← to view the live video.

Congratulations! You have finished Android view successfully, now you can view the live video from your phone.

For Others

Symbian, Windows Phone, Blackberry OS and all others

1. Open http://3g.tenvis.info in your mobile phone browser.

2. Register an account of TENVIS video surveillance system if you do not have.

3. Login with your own account.

4. Please select **Management** for the first time of logining the video surveillance system. Then select **add** to continue.

5. Input camera S/N and camera's username and password.

IP ADD:HTTP://192.168.1.239:81
User: admin   Pwd: <null>
S/N: xxxx
DDNS:http://xxxx.tenvis.info

You can find the label on the cameras

6. Select **Single Channel** to view camera from Internet.

Congratulations! You have finished internet view successfully, now you can view the live video from your phone.

Chapter 5: Last, but not least

FAQ

1. Why my computer or security software said the software is dangerous and it is a virus?

The wizard will detect device in your network, and it seems like a virus. Please ignore the warning and continue.

2. Why the wizard could not detect the camera?

Please make sure the network cable is in normal and turn off firewall and security software in your computer.

3. Why the wizard said The camera can not be accessed , please choose one key set or manual setting after we already done One key set and Manual setting?

Please connect the camera to your router or ADSL router, and **DO NOT** connect it to your PC directly.

4. Why the camera always ask username and password , or it said Incorrect User?

The camera's default username is **admin**, and please leave password blank. If you forget your username or password, you could reset the camera to factory settings to get the default username and password.

5. How can I reset the camera to factory settings?

Please press the reset button under or on the camera about 1 minute until the camera reboot. Please make sure the power supply is connected to the camera when you are doing it.

6. Why there is no audio and video from the camera (Only indoor camera support audio)?

No audio: Please sign in ActiveX mode for IE or VLC mode for all web browsers. No video: IE does not support Server Push mode and other web browser does not support ActiveX mode, please login the correct mode for video. TENVIS mobile application support video but not support audio, you could find some 3rd party application support audio for TENVIS IP camera.

7. Why the image is blurry?

Please tear down the preservative on the lens and rotate the lens of the camera if you could get clear image.

8. Why the camera could not pan/tile properly?

Maybe the camera is stuck. Please rotate its head manually to fix it.

9. Why the camera always lost wireless connection?

Please tighten the antenna of the camera. Make sure it is not far away from the router and there is no big barrier between the camera and the router.

10. The comparison of different browsers.

	IE	Firefox, Chorme, Safari in all platform
Video	Yes	Yes
Record	Yes	No
Alarm Record	Yes(Only in live video page)	No
Alarm by E-mail or FTP	Yes	Yes
Multiple View	Yes	No
Audio	2 Way	No

Learn more

You can find more information, watch demos and learn more about TENVIS IP Camera at *www.tenvis.com*.

Support

If you have any problem of the camera settings, please visit our forum to search your problem or post thread for help.
http://forum.tenvis.com

China Worldwide Customer Service

Time: 9:00-18:00 BJT   Monday-Friday

Telephone #: 0086-0755-89732479

E-mail: *support@tenvis.com*

USA Local Customer Service

Time: 7:00-15:00 MST   Monday-Friday

Telephone #: 1 (505) 715-6577

Skype: tenvis_us_support

E-mail: *ussupport@tenvis.com*

TENVIS

the world in my eyes

TENVIS Technology Co., Ltd

www.tenvis.com