



Place C7 near to the U1 and use power lines associated with U1.

J4/J5 – 230V – 24V 500mA step-down transformer.
 Both U2 and U3 required heat-sinks.
 Both J6 and J7 are two poles of single DPDT push – on / push – off type switch.
 For J1 use common-cathode – red seven segment display.

jaykody20001@gmail.com
 Dilshan R Jayakody
 Sheet: /
 File: speaker_selector.sch

Title: 6 channel speaker / amplifier selector
 Size: User Date: 2018-04-02
 KiCad E.D.A. KiCad 4.0.7-e2-637658bunt16.04.1 Id: 1/1