

STJØRN

SONG RIG 1 / A 2 / B 3 / C

STJØRN

SONG RIG 1 / A 2 / B 3 / C

STJØRN

SONG RIG 1 / A 2 / B 3 / C

STJØRN

LOOP & PAD 6 / E 4 / # 5 / D

LOOP & PAD 6 / E 4 / # 5 / D

LOOP & PAD 6 / E 4 / # 5 / D

LOOP & PAD 7 / F 7 / F 8 / G

LOOP & PAD 7 / F 8 / G 8 / G

CURR SCENE NEXT SONG TALK

CURR SCENE NEXT SONG TALK

CURR SCENE NEXT SONG TALK

NEXT

RIG RIG RIG

NOIS EXPANSION NOIS EXPANSION

NOIS EXPANSION NOIS EXPANSION

NOIS EXPANSION NOIS EXPANSION

NEXT

IN IN IN

FADE UP FADE DOWN

FADE UP FADE DOWN

L2 TAP TEMPO EXP > GTR

NEXT

XOΛ XOΛ XOΛ

TALK XOΛ

STJØRN

TALK IN IN

STJØRN

L2 TAP TEMPO EXP > GTR

RIG 5V DC

STOP AM MOD FDBK +

PLAY R2 DLY LENGTH +

CYCLE D2 VERB UNIT

CYCLE D2 VERB UNDO

FDBK + AM MOD

GOTO 4 CL FLTR FDBK -

L2 TAP TEMPO EXP > GTR

STOP AM MOD FDBK +

PLAY R2 DLY LENGTH +

CYCLE D2 VERB UNIT

CYCLE D2 VERB UNDO

LENGTH + R2 DLY

GOTO 3 R1 COMP LENGTH -

HOLD FOR MENU

GOTO 4 CL FLTR FDBK -

GOTO 3 R1 COMP LENGTH -

GOTO 2 D1 DRV2 STOP / CLR

GOTO 1 L1 DRV1 REC / PLAY

UNIT D2 VERB

GOTO 2 D1 DRV2 STOP / CLR

HOLD FOR MENU

GOTO 4 CL FLTR FDBK -

GOTO 3 R1 COMP LENGTH -

GOTO 2 D1 DRV2 STOP / CLR

GOTO 1 L1 DRV1 REC / PLAY

UNIT D2 VERB

GOTO 1 L1 DRV1 REC / PLAY

HOLD FOR MENU



STJØRN

SONG RIG 1 / A 2 / B 3 / C

STJØRN

SONG RIG 1 / A 2 / B 3 / C

STJØRN

SONG RIG 1 / A 2 / B 3 / C

STJØRN

LOOP & PAD 6 / E 4 / # 5 / D

LOOP & PAD 6 / E 4 / # 5 / D

LOOP & PAD 7 / F 7 / F 8 / G

CURR — SCENE — NEXT SONG

CURR — SCENE — NEXT SONG

CURR — SCENE — NEXT SONG

NEXT

RIG
RIG
RIG

NOIS EXPANSION NOIS EXPANSION 5V DC 5V DC 5V DC

NEXT

IN
IN
IN

NOIS EXPANSION NOIS EXPANSION HOST HOST HOST

FADE UP FADE DOWN
FADE UP FADE DOWN

L2 TAP TEMPO
EXP > GTR

NEXT

XOΛ
XOΛ
XOΛ

TALK XOΛ
TALK IN IN
RIG 5V DC

STJØRN
STJØRN

L2 TAP TEMPO
EXP > GTR

AM MOD
FDBK +

R2 DLY
LENGTH +

D2 VERB
UNIT

D2 VERB
UNDO

FDBK +
AM MOD

FDBK -
CL FLTR

L2 TAP TEMPO
EXP > GTR

AM MOD
FDBK +

R2 DLY
LENGTH +

D2 VERB
UNIT

D2 VERB
UNDO

LENGTH +
R2 DLY

LENGTH -
R1 COMP

HOLD FOR MENU

CL FLTR
FDBK -

R1 COMP
LENGTH -

D1 DRV2
STOP / CLR

L1 DRV1
REC / PLAY

UNIT
D2 VERB

STOP / CLR
D1 DRV2

HOLD FOR MENU

CL FLTR
FDBK -

R1 COMP
LENGTH -

D1 DRV2
STOP / CLR

L1 DRV1
REC / PLAY

UNDO
D2 VERB

REC / PLAY
L1 DRV1

HOLD FOR MENU



Note: Print Layer colour - Magenta & Red normal

STOP

STOP

GOTO 4

STOP

GOTO 3

GOTO 4

GOTO 3

GOTO 2

GOTO 1

GOTO 2

GOTO 4

GOTO 3

GOTO 2

GOTO 1

GOTO 1

CYCLE CYCLE

CYCLE CYCLE

CYCLE

CYCLE

Note: Print Layer colour - Spot Green

PLAY

PLAY

PLAY