
















VIN_3.3 VIN_3.3
SDA SDA
SCL SCL
INT INT
RSTB RSTB







USB switch



5v Boost



Battery charger



PB_IN shared between bq25895 and max16150a.

Short-press: INT toggled low.
Press >8s: BOOST_EN is pulled low.

