


2016 SingleTree Lane, Lancaster PA 17602

Phone: 717-824-4052 • Fax: 717-824-4053 • Toll Free 877-546-2257

E-mail: sales@advancingalternatives.com • www.advancingalternatives.com

8 inches from guide plate to edge of motor



2-3" between the edge of the greenhouse and the guidewheel unless you are using roll lock. When using roll lock you need an external limit switch to control the downward movement of the motor.

5-6" if using roll lock.

The center of the guidepipe needs to be 3 or 4 inches off the edge of the house unless using our roll lock.

If used with our roll lock and external limit switch the guidepipe needs to be 6 or 7 inches off the edge of the greenhouse.