

RELAY STATE TABLE

OPERATION	SSR					
	1	2	3	4	5	6
HIGH SPEED FORWARD	ON	ON	ON	OFF	OFF	OFF
LOW SPEED FORWARD	OFF	ON	ON	ON	OFF	OFF
HIGH SPEED REVERSE	ON	OFF	OFF	OFF	ON	ON
LOW SPEED REVERSE	OFF	OFF	OFF	ON	ON	ON

