

# Nord Service

Spare Parts List

**CLAVIA DMI AB**

service@clavia.se

+46 8 442 73 63

January 2024

Parts (on board level) **NOT** on this list are **NLA - no longer available!**

Latest changes:

## Keyboards

Part#	Description
40169	3 Oct. NMG2
40312	4 Oct. NL2X Ltd Edition / INVERTED KEYS
40162	4 Oct. NL/NL2/NL2X/NL4/NLA1
40005	4 Oct. NL3/NW
40004	5 Oct. NE/NE2/C2/61, uncalibrated
49004	5 Oct. NE3/NE4/NE5/NE6/61, calibrated
40193	5 Oct. NMG2X
49812	5 Oct. NW2 calibrated
40006	6 Oct. NE/NE2 73, uncalibrated
49006	6 Oct. NE3/NE4/73, calibrated (F-F)
49446	6 Oct. NE3HP/NE4HP/NE5HP/NE6HP/NP2HP, calibrated
49589	6 Oct. NE5/NE6/73, calibrated (E-E)
49598	6 Oct. NS2EX/NS3/73Compact, calibrated
49266	6 Oct. NS/NSEX Compact/SW73, calibrated
49843	6 Oct. NP5/73, calibrated
49236	6 Oct. NS/NSEX/NS2/76, calibrated
49597	6 Oct. NS2EX/NS3/HP76, calibrated
49418	7 Oct. NP/NP2 No Aft, calibrated
49619	7 Oct. NP3/NP4/NP5 No Aft, calibrated
40171	7 Oct. NS/NSEX/HA88
49171	7 Oct. NS/NSEX/NS2/NS2EX/NS3/HA88, calibrated
49858	6 Oct. NS4/73, calibrated
49859	7 Oct. NS4/88, calibrated
49865	6 Oct. NS4/73Compact, calibrated
49599	7 Oct. NG / Kawai
40453	Foam strip, 1250*7*10mm
40647	Felt TP40/support (NP3, up to ser#PD11184)
40002	Single key, any model/type



## Lower Lids

Part#	Description
40274	Lower Lid NC10
40343	Lower Lid NC20
40475	Lower Lid NC2D
40669	Lower Lid NE6/61
40671	Lower Lid NE6/73
40673	Lower Lid NE6/HP
40573	Lower Lid NE5/61
40578	Lower Lid NE5/73
40582	Lower Lid NE5/HP
40494	Lower Lid NE4D/61
40522	Lower Lid NE4HP
40524	Lower Lid NE4SW/73
40327	Lower Lid NE3/61
40465	Lower Lid NE3HP
40107	Lower Lid NE/NE2 61
40117	Lower Lid NER/NE2R
40311	Lower Lid NL2X LDT Edition
40168*	Lower Lid NL2X (pre January 2010)
40363*	Lower Lid NL2X (post January 2010) (marked as "v2.0")
40111	Lower Lid NL3
40553	Lower Lid NL A1
40563	Lower Lid NL A1R
40528	Lower Lid NL4
40175	Lower Lid NMG2
40173	Lower Lid NMG2E
40202	Lower Lid NMG2X
40103	Lower Lid NMR
40405	Lower Lid NP
40451	Lower Lid NP2
40441	Lower Lid NP2HP
40617	Lower Lid NP3
40685	Lower Lid NP4
40693	Lower Lid NP4 v2
40823	Lower Lid NP5/88
40841	Lower Lid NP5/73
40655	Lower Lid NG
40369	Lower Lid NPK27
40364	Lower Lid NR2X
40113	Lower Lid NR3
40530	Lower Lid NR4
40261	Lower Lid NS76
40336	Lower Lid NS76 EX
40334	Lower Lid NSC EX
40394	Lower Lid NS2/SW73
40396	Lower Lid NS2/HA76
40398	Lower Lid NS2/HA88
40601	Lower Lid NS2EX/73Compact
40592	Lower Lid NS2EX/76HP
40603	Lower Lid NS2EX/HA88
40611	Lower Lid NS3/73Compact
40613	Lower Lid NS3/76HP
40615	Lower Lid NS3/HA88
40689	Lower Lid NS3/76HP - RevB
40691	Lower Lid NS3/HA88 - RevB

40862	Lower Lid NS4/73Compact
40833	Lower Lid NS4/73 - Rev A
40888	Lower Lid NS4/73 - Rev B (Post ser# SR10768)
40825	Lower Lid NS4/88
40292	Lower Lid NW
40808	Lower Lid NW2

## Upper Lids

Part#	Description
40273	Upper Lid NC1O
40342	Upper Lid NC2O
40474	Upper Lid NC2D
40116	Upper Lid NE2R
40326	Upper Lid NE3 61
40320	Upper Lid NE3 73
40464	Upper Lid NE3HP
40493	Upper Lid NE4D/61
40521	Upper Lid NE4HP
40523	Upper Lid NE4SW/73
40572	Upper Lid NE5/61
40577	Upper Lid NE5/73
40581	Upper Lid NE5/HP
40668	Upper Lid NE6/61
40670	Upper Lid NE6/73
40672	Upper Lid NE6/HP
40552	Upper Lid NL A1
40562	Upper Lid NL A1R
40310	Upper Lid NL2X LDT Edition
40096	Upper Lid NL2
40167	Upper Lid NL2X
40110	Upper Lid NL3
40527	Upper Lid NL4
40174	Upper Lid NMG2
40172	Upper Lid NMG2E
40201	Upper Lid NMG2X
40102	Upper Lid NMR
40404	Upper Lid NP
40450	Upper Lid NP2 HA88 (older rev., w BOURNS pots 20640)
40542	Upper Lid NP2 HA88 Rev 2 v1.1 (w ALPS pots)
40440	Upper Lid NP2HP
40616	Upper Lid NP3
40684	Upper Lid NP4
40822	Upper Lid NP5/88 Rev A
40853	Upper Lid NP5/88 Rev B
40840	Upper Lid NP5/73 Rev A
40852	Upper Lid NP5/73 Rev B
40654	Upper Lid NG
40370	Upper Lid NPK27
40183	Upper Lid NR2X
40112	Upper Lid NR3
40529	Upper Lid NR4
40291	Upper Lid NW
40807	Upper Lid NW2

## Upper Lids ...continuing

Part#	Description
40270	Upper Lid NSC
40333	Upper Lid NSC EX
40260	Upper Lid NS76
40335	Upper Lid NS76 EX
40337	Upper Lid NS88 EX
40393	Upper Lid NS2/SW73 ("REV-B" only)
40395	Upper Lid NS2/76 (REV-A)
40455	Upper Lid NS2/76 (REV-B)
40397	Upper Lid NS2/88 (REV-A)
40457	Upper Lid NS2/88 (REV-B)
40600	Upper Lid NS2EX/73 Compact
40591	Upper Lid NS2EX/76HP
40602	Upper Lid NS2EX/HA88
40610	Upper Lid NS3/73Compact - Rev A
40612	Upper Lid NS3/76HP - Rev A
40614	Upper Lid NS3/HA88 - Rev A
40687	Upper Lid NS3/73Compact - Rev B
40688	Upper Lid NS3/76HP - Rev B
40690	Upper Lid NS3/88 - Rev B
<b>40861</b>	<b>Upper Lid NS4/73Compact - Rev A</b>
<b>40832</b>	<b>Upper Lid NS4/73 - Rev A</b>
<b>40824</b>	<b>Upper Lid NS4/88 - Rev A</b>
<b>40886</b>	<b>Upper Lid NS4/73Compact - Rev B (Post ser# SQ11160)</b>
<b>40887</b>	<b>Upper Lid NS4/73 - Rev B (Post ser# SR10768)</b>
<b>40889</b>	<b>Upper Lid NS4/88 - Rev B (Post ser# SS13123)</b>

## Nord Drum Mechanics + PADS + Piezo mic

Part#	Description
40482	Lower Lid Nord Drum v1.0
40520	Lower Lid Nord Drum v1.2
40535	Lower Lid Nord Drum2
40538	Lower Lid Nord Pad
40481	Upper Lid Nord Drum v1.0
40519	Upper Lid Nord Drum v1.2
40534	Upper Lid Nord Drum2
40570	Upper Lid Nord Drum3P
40537	Upper Lid Nord Pad
40550	Nord Drum Mounting Holder (for mic stands)
42540	Nord Drum 3P, single pad (complete, mounted)
22098	ND3P Piezo mic, short cables (Pad#1-3)
22099	ND3P Piezo mic, long cables (Pad#4-6)

## Side Panels (ONLY SOLD IN PAIR)

Part#	Description
40280/40281	Wood Panel NC1O, Left/Right
40346/40347	Wood Panel NC2O, Left/Right
40478/40479	Wood Panel NC2D, Left/Right
40674/40675	Wood Panel NE6D/61/73, Left/Right
40676/40677	Wood Panel NE6HP, Left/Right
40575/40576	Wood Panel NE5D/61/73, Left/Right
40322/40323	Wood Panel NE3/NE4D-61, Left/Right
40324/40325	Wood Panel NE3/NE4SW-73, Left/Right
40443/40444	Wood Panel NE3HP/NE4HP/NE5HP/NP2HP, Left/Right
40231/40232	Wood Panel NE61, Left/Right
40233/40234	Wood Panel NE73/NSC, Left/Right
40532/40533	Wood Panel NL4, Left/Right
40402/40403	Wood Panel NP, Left/Right
40544/40545	Wood Panel NR4, Left/Right
40215/40216	Wood Panel NS76/88, Left/Right
40400/40401	Wood Panel NS2/SW73, Left/Right
40435/40436	Wood Panel NS2/76/88/NP2/NS2EX88, Left/Right
40604/40605	Wood Panel NS2EX/73 Compact, Left/Right
40595/40596	Wood Panel NS2EX/76HP, Left/Right
40662/40663	Wood Panel NS3/73Compact, Left/Right
40664/40665	Wood Panel NS3/76HP, Left/Right
40625/40626	Wood Panel NS3/NP3/NP4/HA88, Left/Right
<b>40863/40864</b>	<b>Wood Panel NS4/73Compact, Left/Right</b>
<b>40830/40831</b>	<b>Wood Panel NS4/73/88, Left/Right</b>
40834/40835	Wood Panel NP5/73/88, Left/Right
40656/40657	Wood Panel NG
40658	Wood Top Panel NG
40554/40555	Metal Side Panel NL A1, Left/Right
40809/40810	Metal Side Panel NW2, Left/Right

## Rackears (ONLY SOLD IN PAIR)

40086	Rackear NER/NE2R
40186	Rackear NR2X
40543	Rackear NR4
40564	Rackear NL A1R



## Panel boards

Part#	Description
60112	Panel Board NC1O
61084	Panel Board NC2O
60207	Panel Board1 NC2D
60208	Panel Board2 NC2D
60193	Panel Board NE3
60225	Panel Board NE3HP
60234	Panel Board NE4 61
60270	Panel Board NE5D (61/73) (shipped w 60272)
60271	Panel Board NE5 HP (shipped w 60272)
60272	Panel Board NE5 SUB-board
60311	Panel Board NE6D (61/73) (shipped w 60315)
60313	Panel Board NE6 HP (shipped w 60315)
60315	Panel Board NE6 SUB-board
60019	Panel Board NL1
60169	Panel Board NL2X
60244	Panel Board NL4
60259	Panel Board NL A1
60266	Panel Board NL A1R
60172	Panel Board NMG2
61026	Panel Board NMG2X
<b>60037</b>	<b>Panel Board NMK</b>
60041	Panel Board NMR
61078	Panel Board NP
<b>60214</b>	<b>Panel Board NP2 (older HA88, w BOURNS pot 20640)</b>
<b>60253</b>	<b>Panel Board NP2HP (also on newer HA88s, w ALPS pots)</b>
<b>60296</b>	<b>Panel Board NP3</b>
60323	Panel Board NP4
60356	Panel Board 1 NP5
60368	Panel Board 1 NP5
60354	Panel Board 2 NP5
60335	Panel Board1 NG
60337	Panel Board2 NG
60177	Panel Board NR2X
60255	Panel Board NR4
61061	Panel Board NW
60342	Panel Board1 NW2
60344	Panel Board2 NW2
60346	Panel Board3 NW2
60188	Panel Board1 NS/NSEX
61034	Panel Board2 NS/NSEX
60201**	Panel Board1 NS2 ("REV A")
<b>60218**</b>	<b>Panel Board1 NS2 ("REV B")</b>
60203**	Panel Board2 NS2 ("REV A")
<b>60219**</b>	<b>Panel Board2 NS2 ("REV B")</b>
60282	Panel Board1 NS2EX
60283	Panel Board2 NS2EX
60290	Panel Board1 NS3/HA88/76HP - Rev A
60291	Panel Board2 NS3 - Rev A
60292	Panel Board1 NS3/73Compact - Rev A
60325	Panel Board2 NS3 - Rev B
60327	Panel Board1 NS3/HA88/76HP - Rev B
60329	Panel Board1 NS3/73Compact - Rev B
<b>60360</b>	<b>Panel Board1 NS4 - Rev A</b>
<b>60358</b>	<b>Panel Board2 NS4 - Rev A</b>
<b>60376</b>	<b>Panel Board1 NS4 - Rev B (Post ser# SS13123 / SR10768 / SQ11160)</b>
<b>60378</b>	<b>Panel Board2 NS4 - Rev B (Post ser# SS13123 / SR10768 / SQ11160)</b>

\*\* NS2 /SW73 is only shipped as "REV B".

## Mainboards

Part#	Description
<b>60032</b>	<b>Mainboard NL2</b>
<b>60067</b>	<b>Mainboard NL2X</b>
60247	Mainboard NL4/NR4
60261	Mainboard NL A1
<b>60110</b>	<b>Mainboard NC10</b>
61085	Mainboard NC20
60206	Mainboard NC2D
<b>60070</b>	<b>Mainboard NE2</b>
<b>61080</b>	<b>Mainboard NE3</b>
<b>60223</b>	<b>Mainboard NE3HP</b>
60238	Mainboard NE4D/61
<b>60240</b>	<b>Mainboard NE4HP/SW73</b>
60273	Mainboard NE5
60309	Mainboard NE6
60036	Mainboard NM
<b>60077</b>	<b>Mainboard NMG2</b>
<b>60178</b>	<b>Mainboard NMG2E</b>
60205	Mainboard NP
<b>60213</b>	<b>Mainboard NP2/NP2HP</b>
<b>60295</b>	<b>Mainboard NP3</b>
60321	Mainboard NP4
60331	Mainboard NP4 v2
60340	Mainboard NP5
60307	Mainboard NG
<b>61042</b>	<b>Mainboard NSEX</b>
<b>60195*</b>	<b>Mainboard NS2 ("REV B")</b>
60278	Mainboard NS2EX
60287	Mainboard NS3
<b>60362</b>	<b>Mainboard NS4</b>
<b>61058</b>	<b>Mainboard NW</b>
60333	Mainboard NW2
60228	Mainboard Nord Drum (v1.0)
60237	Mainboard Nord Drum (v1.2)
60248	Mainboard Nord Drum 2
60269	Mainboard Nord Drum 3P
60250	Mainboard Nord Pad

\* Only "REV B" boards will be available as spare parts, as this is possible to replace broken "REV A" boards with.

Boards written in red are recommended to send to CLAVIA for service, please contact [service@clavia.se](mailto:service@clavia.se) for further assistance.

## Flashes

21400	64Mb (NE/NE2)
24000	256Mb (NS)
25760	512Mb (NSEX/NW)
25761	1Gb SPANSION (NC2/NE3)
25762	1Gb MICRON (NE4/NP/NS2/NS2EX)
25763	1Gb SPANSION GS (NC2D/NP2/NE3HP)
25764	1Gb MACRONIX (NS2, synth section) - <b>NLA</b>

## DSP/HOST

25654	DSP, SHARC (NE6/NP4/NS3/NL4/NLA1)
25655	Host, TEXAS/ARM (NE6/NP4/NS3/NL4/NLA1)
21360	"DSP362" (NE/NE2/N2X/NL3)
23280	"DSP367" (NS-range/NW/NE3-4-5/NCO-range/NP-range/NMG2)



## Jacks

22590	Connector 1/4" Mono
22600	Connector 1/4" Stereo
22610	Connector 1/4" Stereo/Break
25554	Connector 3.5mm Stereo/Break
25578	Connector 1/4" Mono/Stereo/Break/AllPurpose [Cliff]
25575	Connector 3.5mm Stereo/Break

### Guide

#### 22590 - Mono - "112APC"

Mainly used as **Line Outs** on "**older**" products (pre 2011) and for the Sustain/Rotor jacks.

(NE/NE2/NE3/NE3HP, NS/NSEX, NL/2/2x/3, NP, C1/C2, NW, NM/NMG2)

#### 22600 - Stereo - "112BPC"

Used for Headphones on all products and **Line Outs** on "**newer**" products (post 2011-, NE4/5, NS2, NP2, C2D, NL4)

Even though this is a "stereo jack", the Line Outs are still handling mono signals.

#### 22610 - Stereo/Break - "114BPC"

Mainly used for Control/Swell functions on various products, but also as the sustain jack where the

**Nord Triple Pedal** is used (NE5/NE6/NP/NP2/NP3/NP4/NS2/NS2EX/NS3).

#### 25578 - Mono/Stereo/Break/AllPurpose

New jack used on the NP4v2, NG and NW2 mainboard. This "AllPurpose" jack is used on all positions instead of three different types on the previous mainboard revision.


#### 25554 - Stereo/Break - 3.5mm Monitor In

Introduced on the NE3 range and used on most products today, except on NL4 and NLA1.


#### 25575 - Stereo/Break - 3.5mm Headphones (ND3P)

Ser# DH10986 and below, uses a temporarily (no official part#) 3,5mm jack, patched to the mainboard with cables.

From ser# DH10987 and forward, the 3,5mm connector (25575) is mounted on the



## Encoders, pots and knobs




- 25250 Drawbar/slide pot w detents (C2D/NE4-61/NE5/6-61/73, NS3C/NS4)
- 25255 Drawbar/slide pot - NO detents (NW2/NS4)
- 20640 10k pot (Bourns)
- 24010 Encoder, no detents (NS/NSEX/NS2/NL3/NMG2)
- 25270\* Encoder, w. detents (NS/NSEX/NS2/NS2EX/NW/NMG2)
- 25274 Encoder, w. detents (ND/ND2/NL4/NE5/NE6/NW2/NS3/NS4)
- 25251 Pot, no detents (ND2/NE5/NL4/NP2HP/NS2EX/NS3/NS4)
- 25252 Pot, w. center detent (NE5/6/NL4/NS2EX/NS3/NS4/NLA1/NP4/NG)

- 22900 Knob for 20640
- 22950 Knob for 25270 (NS/NW/NL3/NMG2)
- 25271\* Knob for 25270 (NS/NW/NMG2)
- 25272 Cover/top for 25271
- 25275\*\* Knob for 25274 (ONLY ND/ND2!!!)**
- 50404 Knob for 25251/25252 (ND2/NE5/NE6/NL4/NP2HP/NS2EX/NS3)
- 50405 Knob for 25274 (ND/ND2/NE5/NE6/NL4/NS2EX/NS3)
- 25281 Knob for Half Moon switch
- 40813 Knob for Drawbar NW2

\* NM and NL3 used an older type of encoder that is NLA. 25270 requires some adjustments of the pins when installing it in a NM/NL3, though is fully compatible with the older type.

\*\* 25275 is very similar to 25271, but have a slightly bigger hole for the larger axis on 25274.

## Mod wheel pot



**Part#23041**, the mod wheel pot, used in all Nord Leads and Nord Stages since "day one", is changed from BOURNS to ALPS in new production. The change is valid on products (NLA1/NL4/NS2) made in September 2014 and forward.

The part# on the ALPS pot is **25254**.

The Bourns pot part#, without cables, is **20680**.

Due to the mechanical changes *the old BOURNS type can't be replaced by the newer ALPS model*.

The new mechanical parts, with part#, are shown above.

**When ordering the mod wheel pot, make sure which type that is mounted in the unit.**

**When ordering the old mod wheel (40008), we will ship the whole mod wheel kit, including bracket and pot (25254+40559+40557).**

23041 is also used in the CV-pedal (mounted on the PK27) and will continue so.

<b>23041</b>	<b>Mod Wheel pot / BOURNS - NLA</b> (NL/NL2/NL2X/NL3/NS/NSEX/NW + pre September 2014 NL4/NLA1/NS2 + CV pedal on PK27)
20680	Replaces 23041, ships without cables.
25254	Mod Wheel pot / ALPS (post September 2014 NL4/NLA1/NS2/NS2EX/NS3/NS4/NW2)
40557	Bracket / ALPS
40559	Modwheel / ALPS

## Screws



Part#	Description
40010	Midi
40018	Upper/Lower lid
40019	Circuit boards
40026	Pitch stick
40038	Bumper
40039	Keybed TP8/TP100 (NE/HP-series)
40241	Keybed TP40 (NS/NP-series)
40290	C2D wood panel
40340	Circuit board, brackets
40341	Wood panel
40349	Wood panel, inside
40362	Power switch protection frame
40503	Power board connector, IEC
40561	Side panel NLA1/NW2
40666	ND3P, mounting holder (not pictured)
40695	Lower lid, Nord Piano Monitor (NG/NP4v2/NP5/NS3), M6-size
50408	NLA1 keyboard, trafo on 60300

## Power boards

Part#	Description
60074	Power Board NL3/NE/NE2/NL2X (pre 2010)
60175	Power Board NMG2E
61094*	Power Board Nord EUR/GBR/CHN
60231**	Power Board Nord IEC
60300	Power Board Nord IEC - 12p (NE6/NG/NP4/NP5/NS3/NS4/NW2)
50370***	Power Adapter 12V / Switched (PK27 / ND / ND2)

Boards written in red are recommended to send to CLAVIA for service, please contact [service@clavia.se](mailto:service@clavia.se) for further assistance.

Except for NL2X/NR2X units made before January 2010, 61093/94/95 are equivalent to the previous 69183. For NL2X/NR2X made before January 2010 - continue to use part#60074.

\* Part# 61093/94/95 are used in the NS2-series and replaces the previous model part#69183, also found in the discontinued products C1/NE3/NMG2/NMG2X/NS/NSEX/NS2/NW. Only part#61094 is used today.

\*\* Part# 60231 mounted in the NS2EX/NE5/NE4/NC2D/NP2/NL4/NLA1 are shipped with a 3 pin IEC connector type from November 2012 and forward. A two pin version was previously used.



\*\*\* When used for PK27s, the 12V version is only compatible after ser#10733. For older units use +9VDC with grounded center pin.

60074


61094

60231

60300



Part#	Description
22360	Power Cord 2pin EUR
<b>22371</b>	<b>Power Cord 2pin USA/BRA - NLA!</b>
22380	Power Cord 2pin GBR
22361	Power Cord 3pin IEC EUR
22362	Power Cord 3pin IEC USA/JPN
22366	Power Cord 3pin IEC GBR
22800	Fuse 115V / 300mA (slow) USA/BRA/JPN
22820	Fuse 230V / 125mA (slow) EUR
22840	Fuse holder, mounted on the board
22850	Fuse tip EUR
22860	Fuse tip USA/BRA/JPN



230V/125mA

115V/300mA

## Various spare parts

Part#	Description
25278	Button grey (Previously part#22050)
25277	Button black (Previously part#22030)
25279	Button red (Previously part#22040)
22640	Connector DIN 5 pol Midi
22690	Connector USB Type B
40008	Modulation wheel <b>DISCONTINUED! NLA</b>
24020	Display LCD NS/NW incl cable
25362*	<b>OLED - Display (128*64 pixels) (NES/6/NG/NP3/4/NS3/NW2)</b>
40587*	<b>OLED - Display frame</b>
40588*	<b>OLED - Frame tape</b>
40606*	<b>OLED - Display protection/cover</b>
25365*	<b>OLED - Display (128*32 pixels) (NW2)</b>
40814*	<b>OLED - Display frame (NW2)</b>
40815*	<b>OLED - Frame tape (NW2)</b>
40816*	<b>OLED - Display protection/cover (NW2)</b>
22000	Powerswitch On/Off
10295	Pitch stick complete NS, long
10190	Pitch stick complete, short
23100	EMI-Filter 470pF
23110	EMI-Filter 2,2nF

All prices are approximate and due to change without notice.  
Please contact [service@clavia.se](mailto:service@clavia.se) for latest updates.

**\* When ordering an OLED display, all four parts (25362/40587/40588/40606 or 25365/40814/40815/40816 (NW2)) will be premounted/shipped together as "one OLED".**





### Nord Pedal Keys PK27 - parts

61092	Midi Board
12007	Swell Pedal, complete w mounted cable
20680	Pot, CV-pedal
40373	Wooden Key ("White key")
50370*	Power Adapter 12V (also used with ND2)
40374	Screw for CV pedal

\* PK27s before ser#10733 uses +9VDC with grounded center pin.

If a new PSU is requested for units before this ser#, the customer need to find a new power supply locally. NLA at Clavia.



### Nord Keyboard Stand EX

40432	Spare Part Kit for 12001 (Keyboard Stand EX)
42358	Extention for 12001, short
42359	Extention for 12001, long