


TUBE SOCKET








ASSEMBLY INSTRUCTION



WWW.NIXIETESTER.COM

TUBE SOCKET

RESISTOR

	No.1	IN12, IN12A, IN12B, IN15A, IN15B, ZM1180, ZM1181, ZM1182, ZM1183, ZM1186, ZM1188, ZM1162	8K2
	No.2	LC631, Z566M, Z5660M, Z567M, Z5670M, ZM1040, ZM1041, ZM1042	6K8
	No.3	B5094, B6032, B6033, B6091, LC513, LL-551...8, QS30-1, Z560M, Z561M, ZM1020...3, ZM1025	20K
	No.4	IN18	3K9
	No.5	R Z568M, Z568M, Z5680M, B7037, NL7037, B8033, NL8091, B8091	6K8
	No.6	IN8	8K2
	No.7	IN2	15K
	No.8	IN4	6K8
	No.9	IN14	8K2
	No.10	IN16	15K
	No.11	Z570/3/4M, Z5730M, Z5740M, ZM1080/2/4/5/6/8, B570M, F9080B, TAF1093A, TAF1317A	12K
	No.12	IN17	39K
	No.13	IN1, LC516	12K7
	No.14	IN19A/B/V	12K7
	No.15	IN7	6K8

