
STREAMER I/O
FELIX I/O
RAMBUF/COMM I/O
CTRL BUFF I/O
RAM BUFFER
MONITORIZARE SERIALA
HOST+ DRIVE = BYPASS
+CISO
+TISO
SPY
READ/WRITE TAPE
PORT i
PORTH
PORTA
CORE1
PORTG
CORE429I2.54MM2.54MM
OPEN4x9I
PORTB
PORTF
PORTC
PORTD
PORTE